

MetriCorr

TR-Monitor Installation Manual

All TR-Monitor products



Document: 102618-05

Target format: A4

Release date: Januar 2024

Contents

1	Introduction.....	3
1.1	Terms & abbreviation:.....	3
2	TRM - Specifications & Basic Functions.....	4
2.1	Overview of Basic Functions.....	4
2.2	Specifications (TRM)	5
2.3	Accessories.....	7
2.4	LED indicators & Alarm inputs	8
3	Data transmission & WEBSERVICE	9
3.1	MasterLink – Control Button & “Status LED”	10
4	Installation of TR-Monitor	12
4.1	Schematic example - TRM Basic pack.....	13
4.2	Installation Instructions	14
5	Power Pack for TR-Monitor with UPS/battery charger (102814).....	17
5.1	Specifications – Power Pack for TR-Monitor.....	18
5.2	Re-chargeable battery recommendations	19
5.3	Installation.....	19
5.4	Schematic – TRM & Power pack (Internal connections)	20
5.5	TRM & Power pack (External connections)	20
5.6	Schematic example – Rectifier, TRM & Power pack	21
6	Extra surge protection (External)	22
6.1	TRM Additional Input Surge Protection (102819).....	22
6.2	Schematic example – Extra surge prot. (Rectifier, TRM & Power pack).....	23
7	TR-Monitor Junction Box (102962).....	24
7.1	External connections (TR-Monitor Junction Box)	25
7.2	Schematic example – T/R cabinet	26
7.3	Options (Antennas, battery, AC grid voltage meas.)	28
7.4	Interrupter relay - NC or NO	29
7.5	TRM junction box – Full schematics	30
7.5.1	Schematic - Excl. PSU for AC grid voltage measuring	30
7.5.2	Schematics - Incl. PSU for AC grid voltage measuring	31

1 Introduction

This document describes how to install all of MetriCorr's Transformer/Rectifier Monitoring (TRM) products: The TRM module, "Power pack for TR," and the "TRM junction box" holding extra surge protection, etc.

All TRM products are based on MetriCorr's TR-Monitor module, referred to as "TRM", which is able to perform measurements on 3 analog inputs, receive alarms on 3 logic inputs, control an external interrupter relay and communicate via LTE & GPS connections. Similar to MetriCorr's Slimline series of dataloggers, the TRM holds a "MasterLink" for data communication with WEBSERVICE, which is MetriCorr's online remote monitoring system. (CP manage)



Go www.metricorr.com for more information and operation instructions for WEBSERVICE.

The TRM is designed to monitor various types of Rectifiers for cathodic protection of pipelines and other metal structures.

1. Pipe to reference electrode potential
2. Rectifier output current.
3. Rectifier output voltage.
4. Instant Off Interrupter, that is time synchronized with MetriCorr dataloggers
5. Off-potentials measurements

This "TR-Monitor Installation Manual" can also be downloaded at www.metricorr.com/downloads.

1.1 Terms & abbreviation:

TRM	Transformer Rectifier Monitor.
T/R	Transformer Rectifier feeding the pipe/structure with DC-current.
Pipe	Refers to buried metallic pipeline or other metal structure.
Rectifier	Transformer Rectifier feeding the pipe/structure with DC-current.
Interrupter	Switch/breaker/relay connected between rectifier and pipe to interrupt the current to the pipe.
Off-potential	Pipe-potential immediately after the cathodic protection current have been cut off. (Interrupted)
WEBSERVICE	MetriCorr's online cathodic protection management software, which is also known as "CP*Manage"
MasterLink	Integral part of the TRM, which handles data communication, etc.
Datalogger	Integral part of the TRM, which performs measurements on the sensor inputs.
SPD	Surge Protection Device

The TRM terminals are referred to by "TRM" followed by the name of the given terminal in parentheses.

In example: "TRM (Power, Primary, 24V)".

2 TRM - Specifications & Basic Functions

2.1 Overview of Basic Functions

<p>POWER</p> <p>PRIMARY: Normal power source (Power supply from mains)</p> <p>SECONDARY: Backup power source (Battery)</p>	<p>LAN</p> <p>RJ45 socket for ethernet</p>	<p>COMMUNICATION</p> <p>RS232: GND, RX, TX Serial communication</p> <p>IN, OUT, SUPPLY: Software controlled Relay for powering peripheral units.</p>	<p>ANTENNAS</p> <p>GPS: Position and Time sync.</p> <p>GSM/LTE Mobile network</p>	<p>Status/Control</p> <p>Control button & LED indicator</p> <p>See section 3.1 for Blink patterns</p>
---	---	---	--	---



INTERRUPTER (Output)

RELAY:
NO: Normally Open
NC: Normally Closed
COM: Mid terminal

Controls external switch/interrupter for the rectifier.

ALARMS (Inputs)

TAMPER: (Tamper LED)
For door switch, etc.
Normal: Switch open, LED: Green
Alarm: Switch closed, LED: Red

POWER: (T/R Power LED)
For T/R Power Failure
Power OK, LED: Green

BATTERY:
For Battery fail signal.
Battery NOT OK, LED: Red

SENSORS (Datalogger inputs)

POTENTIAL:
Voltage measurement between pipe and reference electrode

VOLTAGE:
Voltage measurement for rectifier output.

SHUNT:
Voltage input in the mV range.
Connect to an external shunt resistor to measure current.

2.2 Specifications (TRM)

POWER (Input)

Voltage range: (Primary & Secondary) [10V -> 28Vdc]

Supply voltage	Standby current, max.	Average current (Estimated)	Maximum current
12V dc supply	16 mA	22 mA	100 mA, (1.2W)
24 Vdc supply	12 mA	16 mA	45 mA (1.08W)

LAN

RJ45 socket for LAN/ethernet connection

COMMUNICATION

This 5 pin connector enables power and communication to an external RS232 device.

RS232 interface GND, RX, TX

Supply In & Out Software controlled relay for powering peripheral units. Timing can be set in WEBservice.

ANTENNAS

GSM/LTE antenna 2G / 3G / 4G / 5G

GPS antenna GPS / GNSS

Status/Control

See section 3.1 MasterLink – Control Button & “Status LED”

INTERRUPTER

This relay output controls interruption of cathodic protection current for off-potential measurements. The relay combines a bi-directional Solid State Relay and a mechanical relay for fast response time and true “Normally closed” operation” in case of power down.

Relay specifications:

Type: Bi-directional Solid State Relay + mechanical failsafe relay

Maximum peak voltage: ± 30 V

Maximum current: 500 mA

Note! The connection from rectifier to pipe will be removed when the 3way terminal block for the relay is removed from the TRM.

For higher currents (> 500 mA) an external relay can be controlled using this output. See section 4.

[Installation of TR-Monitor](#)

ALARMS

These 3 inputs are logical HI or LO and galvanically isolated from each other and all other inputs and outputs.

Voltage range: [0Vto 30V]

HI state minimum voltage: 2.5V

LO state maximum voltage 0.7V

TAMPER: Typically used for door switch

POWER: Typically connected to a “Power monitor” output from the UPS or T/R if available.

BATTERY: Typically connected to an UPS/battery charger/controller that indicates low battery voltage.


SENSORS (Datalogger inputs)

POTENTIAL (REF input to PIPE input) and VOLTAGE (“+” input to “-“ input)			
Electrical characteristics	Voltage range:	$\pm 100 V_{DC}$ $100 V_{AC}$	
	Input resistance	$\sim 10 M\Omega$	
	AC to DC rejection	- 80 dB	
	DC voltage resolution:	0.1 mV	
	DC voltage accuracy:	$\pm 1mV \pm 0.3\%$	
	AC Voltage Resolution	0.1 mV	
	AC Voltage Accuracy	$\pm 1mV \pm 1\%$	
Surge Protection	EN/ISO 61000-4-5, installation class 4.		
	Nominal Discharge Current 8/20 μs	5 kA	
	Lightning Impulse Current 10/350 μs	1 kA	
Isolation voltage	2.5 kV for 1 second	Isolation voltage to all other inputs	

SHUNT (“+” input to “-“ input) <i>Millivolt input for current measurement using an external shunt resistor</i>			
Shunt selection (Examples)	Recommended DC Voltage range for shunt selection, max	$\pm 200mVdc$	
	Rectifier output 100A	125A / 60 mV	Shunt resistance 0.48 m Ω ($P_{max} = 6.0W$)
	Rectifier output 20A	25A / 150 mV	Shunt resistance 6.0 m Ω ($P_{max} = 3.0W$)
	Rectifier output 3A	4A / 150 mV	Shunt resistance 37.5 m Ω ($P_{max} = 0.45W$)
	WEBSERVICE calculates the corresponding current from a user-determined shunt resistance value.		
Electrical characteristics	Absolute max. continuous voltage	$\pm 100 V_{DC}$ $100 V_{AC}$	
	Voltage range (peak, incl. AC)	$\pm 1 V$	Before clipping
	Input impedance	33 k Ω	(Resistive)
	AC to DC rejection	-80 dB	
	DC voltage resolution	0.2 μV	(0.2mA @ 1m Ω , 2 μA @ 100m Ω)
	DC voltage accuracy	$\pm 1 \mu V \pm 0.1\% rdg$	(1mA $\pm 0.1\% rdg$ @ 1 m Ω , 10 μA @ 100m Ω)
	AC Voltage Resolution	0.2 μV	(0.2mA @ 1m Ω , 2 μA @ 100m Ω)
AC Voltage Accuracy	$\pm 5 \mu V \pm 0.1\% rdg$		
Surge Protection	EN/ISO 61000-4-5, installation class 4.		
	Nominal Discharge Current 8/20 μs	10 kA	
	Lightning Impulse Current 10/350 μs	2.5 kA	
Isolation voltage	2.5 kV for 1 second	Isolation voltage to all other inputs	

General	
Casing	IP20, DIN-rail mount
Operating temperature range	-40 °C to +85 °C
Dimensions	L: 156mm, W: 60mm H: 86mm

MasterLink	
Storage capacity	+200,000 readings
Logging intervals	10 min → ∞, recommended 1 hour
Communication	LTE Cat. M – 4G/5G with 2G fall back Ethernet RS232 GPS/GNSS Position and Time Synchronization



2.3 Accessories


Connectors with screw terminals: 3 pin, 4 pin, 5 pin, 6 pin and 6 pin (wide)

TR-Monitor installation manual, A4 booklet

2.4 LED indicators & Alarm inputs

The three LED indicators on the left side of the front panel indicates the status of the TRM alarm inputs, which can be either logically low or high.

- **“T/R Power”** is dedicated to show the status of the T/R to be monitored. Many T/R's are equipped with a “Power monitor” signal output that can be connected to the TRM (Power) inputs.
- **“Battery”** is dedicated to indicate if a connected battery is discharged or defect. Battery powered UPS supplies are often equipped with a status signal output that can be connected to the TRM(Battery) input.
- **“Tamper”** is dedicated to i.e. a door-switch to indicate intrusion/access to the TRM-installation.



The three LEDs will light up red or green according to the following table:

Logical Input Level	Low	Unconnected	High
LED Indication			
T/R Power	Green	OFF	OFF
Battery	OFF	OFF	Red
Tamper	Green	Green	Red

If all TRM (ALARM) input terminals are left unconnected, the “T/R Power” and “Battery” LEDs will be turned off and the “Tamper” LED will be green.

3 Data transmission & WEBSERVICE

Measurement data from the sensor inputs can be transmitted by the MasterLink via mobile network or ethernet connection using MetriCorr's WEBSERVICE. <https://data-metricorr.com>.

MasterLink data communication

1. **Mobile network** wireless LTE/GSM to WEBSERVICE
2. **Ethernet** cable connection to external router/modem

New customers must provide company name and email address to MetriCorr to receive account information (username and password) to login to WEBSERVICE at <https://data-metricorr.com>.


Please contact MetriCorr at support@metricorr.com

It is possible to acquire several logins (username and password) to the same WEBSERVICE account.

To link a new MetriCorr device to an existing account, please send an email to support@metricorr.com with the following information:

- **Account Name** (existing or new) you wish the unit(s) to be assigned to.
- **User email address** (for new users to log in to existing or new accounts)
- **MasterLink Serial Number(s)** you wish to link to the account

3.1 MasterLink - Control Button & “Status LED”



TR-Monitor

The Blue Status LED indicates the state of the TRM.

Pressing the control button shortly (< 0.5s) may result in any of the two LED flash patterns below:

25 short blinks indicates that the unit is turned off. This state is rarely used for other applications than MetriCorr’s VL100/MasterLink with built-in lithium battery.




11 blinks indicates that the unit is in “Sleep mode”, which minimizes the current consumption, ideal for battery operated installations.



Pressing the control button for at least 5 sec will turn the unit on or off.

Pressing the control button for at least 1 sec, but less than 5 sec will put the MasterLink in “Searching” mode, indicating that WEBSERVICE or COM port communication is attempted.

	WEBSERVICE	
Searching	The TRM is searching for a network.	
	<p>1 short (0.5 ms) flash repeated every second.</p>	
Transmitting	The TRM is transmitting data to WEBSERVICE	
	<p>3 short (0.5 ms) consecutive flashes repeated every second.</p>	
Sleep mode	<p>After data transmission has been performed, the unit will go into “Sleep mode”, indicated by a short blink every 8 second.</p>	
Measuring (Datalogging)	<p>When the unit is performing measurements, the LED will blink once a second.</p>	



4 Installation of TR-Monitor


MetriCorr's TRM is designed for easy installation in existing rectifier installations for cathodic protection. This section describes how the TRM is installed in a typical installation of a rectifier for cathodic protection of a pipeline. See the schematic in section [4.1 Schematic example - TRM Basic pack](#)

For this example, the existing installation consists of the following components:


- Rectifier
- Relay / Interrupter (of rectifier current)
- Anode bed
- Reference electrode
- Door Switch (Normally closed)

TRM & peripheral components to be installed:

- TRM (MetriCorr)
- Power supply (12 Vdc or 24 Vdc, minimum 5W)
- Antennas (GSM/LTE and GPS)
- Battery (optional, for backup power in case of power outages)




Top view,
MetriCorr
TRM



Bottom view,
MetriCorr
TRM

4.1 Schematic example - TRM Basic pack



Note! This example shows how an external relay that is true “Normally Closed” can be connected to the TRM’s “Normally Open” output. If the external relay is a “Normally Open” type such as a solid state, then the internal “Normally Closed” relay can be used to control the external relay.

It is recommended to use an external relay that can keep a closed position when the power is off.

4.2 Installation Instructions


1. Select the shunt to make sure that the maximum voltage across the shunt does not exceed ± 200 mVdc under normal full range operation. (At maximum rectifier output current).
2. Make sure that the control voltage of the installed “Relay / interrupter” match the power supply level, i.e. 24 Vdc.

SENSORS (Datalogger inputs)

1. Connect the reference electrode to both TRM (POTENTIAL, Ref) and the dedicated input terminals on the rectifier if available.
2. If **two pipe connections** exist, connect the second pipe connection directly to TR-M (PIPE) and the rectifier measurement input as shown on the schematic, section 4.1. (This will minimize the error from the voltage drop across the pipe cable for better measurement and rectifier accuracy).
If only **one pipe connection** exists, connect TRM (PIPE) to TRM (SHUNT, +) and the rectifier measurement input, so both inputs are connected to the pipe.
3. Connect both TRM (VOLTAGE) terminals to the rectifier output terminals as close to the rectifier output terminals as possible. (To minimize errors due to voltage drop across the cables to anode and pipe).
4. Connect TRM (SHUNT, +) to the shunt terminal towards the PIPE.
Connect TRM (SHUNT, -) to the shunt terminal towards the T/R.
This connection will result in a positive current value in relation to the normal current direction indicated with arrows on the schematic, section 4.1.

INTERRUPTER

1. **Internal relay:** Use the terminals TRM(Relay, COM and NC) to insert the built in relay between T/R and PIPE (Max 500mA).
2. **External relay:** The TRM (Relay, COM) terminal is typically connected to V+ to enable drive current to an external relay through the terminals “NO” (Normally Open) or “NC” (Normally Closed). See the example in section 4.1.



The TRM keeps the relay output in normal position when the TRM supply is down.

Make sure that an externally connected relay/interrupter is connected to either the NO or the NC terminal of the TRM, so that the T/R is connected to the pipe during normal operation.


Note: If the TRM is removed from installation, then it is necessary connect the COM and NC wires in the RELAY cable connector to preserve a pipe connection.

ALARMS

1. Connect a door switch to TRM (TAMPER, -) and V-.
Connect TRM (TAMPER, +) to V+.
If there's no door switch, leave both TAMPER inputs unconnected.
2. Connect TRM (POWER, - and +) to the rectifier power monitor outputs if available. Otherwise leave both TRM(POWER) inputs unconnected.
3. UPS/Battery power supplies are typically equipped with a status output signal that can be connected to the TRM (BATTERY) inputs. (Not shown on the schematic, section 4.1).
However, this example uses the secondary power input for battery backup supply. Here, the TRM (BATTERY) inputs can be left unconnected.

POWER

1. Connect the DC power supply (12 Vdc to 24 Vdc) to the TRM (POWER, PRIMARY) inputs.
"24V" is referred to as "V+". "0V" is referred to as "V-".
The AC/DC power supply must be connected to the same AC supply as the rectifier to enable the TRM to monitor the AC supply to the rectifier.
2. Connect backup battery (or other backup power supply) to the TRM (POWER, SECONDARY) inputs.
Note! The TR-M module will internally connect to either the primary or secondary input due to the following conditions:
 - Primary input connected if the primary power supply is available.
 - Secondary input connected if the primary power supply is NOT available.



LAN & COMMUNICATION

1. Typically, the TRM communicates with WEBSERVICE via the GSM/LTE antenna.
2. The TRM has a LAN connector, and it can optionally be delivered with a setup for a LAN network.
Contact MetriCorr for network requirements
3. RS232 communication is not in use

ANTENNAS


1. A GSM/LTE antenna that meets the requirement of the available network in your area must be connected to the TRM (ANTENNAS, GSM/LTE) terminal to establish wireless data connection for the MasterLink.
2. Reception of GPS coordinates and time stamps for synchronization of multiple TR-Monitors for off-potential measurements can be realized in two ways:
 - a. A dedicated GPS/GNSS antenna can be connected to the TRM (ANTENNAS, GPS) terminal. This antenna must have unblocked access to the sky to receive data from the required satellites.
 - b. If no external antenna is connected to the TRM (ANTENNAS, GPS) terminal, the internal GPS/GNSS antenna on the TRM circuit board can be used.

Changing between Internal and External GPS/GNSS antenna can be done in the Setup menu in WEBSERVICE.

5 Power Pack for TR-Monitor with UPS/battery charger (102814)

MetriCorr offers a compact DIN-rail based power supply solution for the TR-Monitor including an uninterruptible power supply with optional battery backup time up to 280 hours and surge protection between grid supply and Pipe connection. Recommended batteries are described with wide temperature range up to 65°C.

Combined with the “TRM Basic Pack”, the “Power Pack for TR-Monitor” can be delivered fully wired and tested as shown on the picture below, or as separated customer specified components.



Features

- Universal AC supply (90 V to 264V)
- Power down detection (AC supply not ok)
Indicated by the “T/R Power LED” and in WEBSERVICE
- Battery voltage is monitored by WEBSERVICE
- Tamper (door switch) detection
Indicated by the “Tamper LED” and in WEBSERVICE
- 12V re-chargeable “Lead Acid” or “Lead Crystal” battery can be used

5.1 Specifications - Power Pack for TR-Monitor

General

Ingres protection	IP20
Temperature range:	-30°C to +70°C
DIN-rail	Standard TS-35/7.5 DIN-rail cut to length: 370mm
Total dimensions of components	W:320mm, H:120mm, D:103mm (including wiring)

UPS/Battery charger

Manufacturer - Part number	MeanWell – DRC-60A
Input Voltage range:	90 VAC to 264 VAC
Nominal battery voltage:	12 VDC (battery not included)
Battery charge current, max.	1.7 A
Indicator outputs	“Low battery” and “AC OK”, see note 1 and 2.
Adjustable voltage level to match optimal cell charge voltage for external battery:	
Output voltage range:	11.7 V to 15.3 VDC, see section 5.3.
Dimensions:	W:40mm, H:90mm, D:100mm

¹The battery low indicator output is not used, because the TRM monitors the battery voltage at all time using the TRM's secondary input that is also connected directly to the battery.

² When the AC supply connected to “L” and “N” on the UPS is down, the UPS activates the “TRM alarm power” input and the “T/R Power” LED indicator on the TRM will turn off. Normally, when AC supply is available, this LED will be green.

Surge protection - Mains supply

(Limiting surges from the mains supply (grid))

Manufacturer - Part number	DEHN – DG M TN 2P 275
Replaceable cartridges:	DG MOD 275 DG MOD NPE
Surge discharge current (8/20us)	20 kA
Residual voltage, max.	1.5 kV
Dimensions:	W:36mm, H:90mm, D:73mm

Spark gap – Pipe to PE

(Limiting surges between Pipe and “Mains PE connector”)

Manufacturer - Part number	Mersen – STMT1-50K150V-1P
Surge discharge current (8/20us)	50 kA
Lightning Impulse Current (10/350us)	50 kA
Residual voltage, max.	2.0 kV
Dimensions:	W:36mm, H:90mm, D:73mm

DIN-terminals

- 2 x PE-screw terminal
- 3 x 4-way terminal
- 1 x fuse terminal for standard 5 x 20mm fuse cartridges.
- 1 x fuse, T3.15A

When the battery voltage drops below 10.1V, the UPS/charger will shut down, but the TRM will function since it is connected directly to the battery via its secondary input.

The “Battery” LED will always be off, since the “Battery alarm” input on the TRM is not used.

5.2 Re-chargeable battery recommendations


MetriCorr recommends Lead crystal batteries due to their wide temperature range and life expectancy. As a standard option we can supply a 12V/7.2Ah Lead Crystal battery (Article number: 102984) as backup battery, which is also used in our TRM box products: “TRM junction box”, “Interrupter & TRM” and “Rectifier & TRM”.

MetriCorr Article number	Type	Life expectancy at 25°C	Nominal voltage / Capacity	Optimal charge voltage	Dimensions LxWxH (Weight)	Temperature range	Backup time
102984	Lead Crystal battery	8-11 years	12V / 7.2Ah	13.38 VDC (@65°C)	151x65x102mm 5.9"x2.6"x4.0" (2.2kg / 4.6 lbs)	-40°C to +65°C	167 hours
100775	Lead Crystal battery	8-11 years	12V / 12Ah	13.38 VDC (@65°C)	151x99x102mm 5.9"x3.9"x4.1" (4.1kg / 7.7 lbs)	-40°C to +65°C	280 hours
101457	Lead Acid	3-5 years	12V / 2Ah	13.20 VDC (@50°C)	150x20x89mm 5.9"x0.79"x3.5" (0.7kg / 1.54 lbs)	-20°C to +50°C	46 hours


5.3 Installation

1. Connect Door switch (normally closed, when cabinet door is open) to terminal “2” and “Tamper –”.
2. Optional: Connect a PE-wire from i.e. a ground rod (earth) to the PE terminal on the red DEHN surge device.
Normally, it is adequate to avoid using this extra PE terminal when the AC supply comes as a standard 3-wire connection including a PE-wire.
3. Connect Pipe, Reference electrode, Shunt resistor, Interrupter/Relay, Transformer/Rectifier output and antennas as described in section 4. See also the schematic example, section 5.6.
4. Connect AC grid supply (mains) to the terminals L, N and PE according to the schematic, section 5.4. **NOTE! The power input to the UPS/battery charger must be connected to the same AC supply as the rectifier to be monitored to ensure that the “T/R Power” alarm works properly. See schematic example, section 5.6.**
5. Before connecting the battery, use a voltmeter to measure the battery charge voltage on terminal “3” and “4”.
6. Adjust the trimmer “+V ADJ” on the UPS/Battery charger according to the optimal charge voltage from the battery datasheet (floating charge voltage, i.e. 13.38 V). Note voltage: _____
7. Connect the battery to terminal “3” and “4”.


5.4 Schematic - TRM & Power pack (Internal connections)



5.5 TRM & Power pack (External connections)



5.6 Schematic example - Rectifier, TRM & Power pack



6 Extra surge protection (External)

MetriCorr's surge protection design against high voltage surges is built around Surge Protection Devices (SPDs) that limits surge voltages to a certain level (i.e. 2 kV) by conducting the surge current, which eliminates the need for high isolation voltage of the equipment. Here, it is the current handling capability of the SPDs that indicates the level of surge protection along with the duration of the surge. The "Nominal Discharge Current, 8/20us" is relevant for incoming surges from the mains AC supply, where the longer pulse current "Lightning Impulse Current, 10/350us" is relevant for applications that are directly exposed to lightning induced currents such as buried pipelines.

The internal surge protection of MetriCorr's TR-Monitor is designed along with coordinated external SPDs to provide extremely rugged surge protection of 50 kA (10/350us) at a reasonable cost. MetriCorr provides a "TRM Additional Input Surge Protection" of three spark gaps and two surge coils.

Mains AC supply (grid) connected installation:

For mains connected installations, surge protection between "Pipe" and "Grid", as found in the "Power pack for TRM", is needed to prevent high surge voltages to damage the TRM.

In addition to the SPDs found in the "Power pack for TRM", the "TRM Additional Input Surge Protection" holds three spark gaps that must be connected between the following connection points:

1. Pipe "Drive" to Anode
2. Pipe "Drive" to PE (earth)
3. Pipe "measurement" to Reference electrode

along with two surge coils (aircoils) as shown on the illustration, section 6.2.

6.1 TRM Additional Input Surge Protection (102819)

Valid for both POTENTIAL (Pipe-Ref) input and VOLTAGE input of the TR-Monitor. At normal use, the SHUNT input of the TR-M is connected to the same Pipe or metal-structure, which will therefore not require any further protection of the SHUNT input. However, if the SHUNT input is connected to another metal structure, which is electrically isolated from the pipe or metal-structure connected to any of the POTENTIAL or VOLTAGE inputs, it is recommended to add extra surge protection for the SHUNT input too.

Specifications:

Spark gaps


Manufacturer - Part number	Mersen – STMT1-50K150V-1P
Surge discharge current (8/20us)	50 kA
Lightning Impulse Current (10/350us)	50 kA
Dimensions:	W:36mm, H:90mm, D:73mm

Surge coils

(Aircoils, limiting surge current to the TRM inputs)


Manufacturer - Part number	MetriCorr
Wire gauge	AWG 18 (1mm ²)
Dimensions	Ø:110mm, W: 10mm

6.2 Schematic example - Extra surge prot. (Rectifier, TRM & Power pack)



7 TR-Monitor Junction Box (102962)


MetriCorr provides a junction box that holds a TR-Monitor module with additional components as shown below to be installed next to an existing T/R cabinet with shunt and interrupter relay.



The “TR-Monitor junction box” holds a “Power pack for TRM” described in section 5.

MetriCorr can provide three prepared cables of customer specified length to be connected between the existing rectifier cabinet and the TR-Monitor junction box.

Default cable length is 2 meters, which is adequate for when the “TRM junction box” is mounted right next to the existing T/R cabinet.




7.1 External connections (TR-Monitor Junction Box)

The schematic below shows how to connect the three external cables, which can be provided by MetriCorr: Measurement cable (5x2.5mm²), Signal cable (10x0.25mm²) and Mains cable (3x1.5mm²).

TR-Monitor Junction Box


Item no.: 102962
 Cabinet dimensions: 40x40x20cm (15.75"x15.75"x7.9")
 Cabinet height incl. cable glands & antenna: 47.5cm (18.7")

ANT.1
 GPS & LTE
 Antenna



7.2 Schematic example - T/R cabinet

The schematic below shows an example of how the three external cables from the TRM junction box can be connected to an existing T/R cabinet with a “Normally closed” Interrupter relay, a shunt connected between rectifier and anode and a door switch (Normally closed when door is open).



Measurement cable (5x2.5mm²)


1. Connect the BROWN wire from SPD.3 to the positive rectifier terminal.
2. Connect the BLUE wire from T.5 to the negative rectifier terminal.
3. Connect the BLACK wire from the upper terminal on SPD.3 to pipe or structure.
4. Connect the GREY wire from SPD.4 to a reference electrode terminal in the existing rectifier cabinet if any, or connect the reference electrode cable directly to SPD.4 as indicated with the yellow dashed line.
5. Connect the GREEN/YELL
6. OW wire from T.6 to ground/chassis of the rectifier cabinet.

Signal cable (10x0.25mm²)

TRM junction box terminal	Wire color	Tag	Connections inside the existing T/R cabinet
T.7	WHITE/BROWN	GND	Connect the input of the interrupter relay to "GND" and "Relay+". (12VDC)
T.8	BLUE/RED	+12VDC (max 2A)	
T.9	GREEN/YEL	Relay +	
T.10	PINK	Shunt +	Connect the shunt to "Shunt +" and "Shunt -"
T.11	GREY	Shunt -	
T.12	VIOLET	Tamper 1	Example: Connect "Tamper 1 and 2" to a door switch.
T.13	BLACK	Tamper 2	
			Door closed ~ Switch open ~ TRM, Tamper LED = GREEN Door open ~ Switch closed ~ TRM, Tamper LED = RED
T.14	Shield	GND	Don't connect shield in the T/R cabinet.

Connect the shield of the signal cable to T.14. Normally it is not necessary to connect the shield at the opposite end of the signal cable (rectifier cabinet), since the PE-wire (green/yellow) of the measurement cable (5x2.5mm²) establish ground connection from TR-Monitor junction box to the existing rectifier cabinet.

Note! Make sure that unused wires do not short to ground or each other!



Mains cable (AC supply)

Connect L (BROWN) and N (BLUE) wires to circuitbreaker CB.1 and the GREEN/YELLOW PE-wire to terminal PE.3 (Protective Earth). MetriCorr recommends to connect the mains cable to the same AC grid source (circuit breaker) as the T/R cabinet.

Reference electrode

As shown on the schematics, the grey wire (5x2.5mm² cable) can be used to connect to the reference electrode via the existing T/R cabinet. However, it is also possible to connect a reference electrode directly to

the TRM junction box as indicated with the dashed yellow line on the schematic, section 7.1.

Earth wire (optional)

It is possible to connect an earth wire to a ground rod or other earth connection via an M12 cable gland mounted at the bottom of the TRM junction box.

7.3 Options (Antennas, battery, AC grid voltage meas.)

Antennas

Per default, MetriCorr installs an LTE & GPS antenna on top of the junction box as shown on the pictures. Please note that the GPS time sync. function requires direct unblocked access to the sky. If this can't be achieved, it is possible to use antenna extension cables through the two M12 cable glands mounted on the bottom of the junction box. Contact MetriCorr for further details.

Backup battery

As a standard option MetriCorr installs a 12V/7.2Ah (-40C to +65C) lead crystal battery, which provides up to a week of backup power.

It is also possible to operate the TRM junction box without battery relying solely on AC grid power.




Power supply for AC grid voltage measuring

The AC grid voltage can be measured and viewed in WEBservice by adding an optional power supply (PSU.2) for this purpose.

MetriCorr's TRM module measures the voltage level on the two primary/secondary inputs, see section 2, where the primary input is fed from PSU.2.

PSU.2 can be wired for either 115VAC or 230VAC. Schematics are displayed in section 7.5.

The UPS/battery charger (PSU.1) accepts universal AC supply (90 V to 264V).



7.4 Interrupter relay - NC or NO

The TR-Monitor junction box is per default wired to control a “Normally Closed” interrupter relay as shown in the schematic examples. Here, the connection from T/R to pipe is preserved if the relay control outputs from the TRM-module are removed or damaged.


DC Solid State relays based on mosfets require an input voltage to conduct current from T/R to pipe and are therefore always “Normally Open”. However, the wiring of the TRM junction box can easily be changed to control Solid State relays as interrupters or other “Normally Open” types of relays. Connect the output relay on the TRM module as indicated in the table below and the schematic to the right.

Interrupter relay type	TRM relay output (Yellow wire)
Normally Closed (Mechanical) (AC solid state)	Connect yellow wire from T.9 to NO (Solid line)
Normally Open (DC Solid State)	Connect yellow wire from T.9 to NC (Dashed line)

Using the TRM backup battery, the TRM module will maintain a voltage output to keep an external solid state relay ON if an AC grid power outage occur.

Fail-safe relay

Using a “Normally open” relay as interrupter in the T/R cabinet, it is possible to install an additional mechanical fail-safe relay in parallel to secure pipe-rectifier connection even if the AC power supply to the “TR-Monitor junction box” fails.



7.5 TRM junction box - Full schematics

7.5.1 Schematic - Excl. PSU for AC grid voltage measuring


TR-Monitor Junction Box

Item no.: 102962

Cabinet dimensions: 40x40x20cm (15.75"x15.75"x7.9")

Cabinet height incl. cable glands & antenna: 47.5cm (18.7")

ANT.1
GPS & LTE
Antenna



7.5.2 Schematics - Incl. PSU for AC grid voltage measuring

Wired for 115VAC

TR-Monitor Junction Box

Item no.: 102962


Cabinet dimensions: 40x40x20cm (15.75"x15.75"x7.9")

Cabinet height incl. cable glands & antenna: 47.5cm (18.7")

ANT.1

GPS & LTE
Antenna

MetriCorr



Wired for 230VAC

TR-Monitor Junction Box

Item no.: 102962


Cabinet dimensions: 40x40x20cm (15.75"x15.75"x7.9")

Cabinet height incl. cable glands & antenna: 47.5cm (18.7")

ANT.1

GPS & LTE
Antenna

MetriCorr



Please visit:

www.metricorr.com



MetriCorr

Toerringvej 7

2610 Rodovre

Denmark

Phone: +45 92 80 80

Email: support@metricorr.com