




# Series ULT Ultrasonic Level Transmitter

## Specifications - Installation and Operating Instructions



Series ULT Ultrasonic Level Transmitter provides reliable, accurate, noncontact measurement of liquid levels. Ultrasonic non-contact technology offers no moving parts to wear, jam, corrode, or get coated like contact technologies. Mapping software makes effective measuring surface only a 3" diameter column. No concerns with ladders, pipes, or other tank intrusions in the remaining sound cone. Unit is FM approved explosion-proof making it ideal for use in hazardous locations. The ULT features easy programming with 6 digit LCD display and simple menu structure. Output range is adjustable with choices of inputting tank dimensions or just fill and empty the tank while calibrating and it automatically scales to levels it senses. Window cover allows early viewing of display. Failsafe output options and diagnostic capabilities makes the ULT a good choice for critical applications.

MODEL CHART			
Example	ULT	1 1	ULT-11
Series	ULT		Ultrasonic level transmitter
Range		1	24.6' (7.5 m)
		2	32.8' (10 m)
Options		1	2" NPT male process with 1/2" NPT female conduit
		2	2" BSPT male process with M20 conduit

### SPECIFICATIONS

**Service:** Compatible fluids. Not for use with powder and bulk solids.  
**Wetted Materials:** Sensor: PVDF; Process connection: 303 SS.  
**Ranges:** 24.6' (7.5 m), 32.8' (10 m).  
**Accuracy:** ±0.2% of maximum range.  
**Resolution:** 0.079" (2 mm).  
**Blind Zone:** Under 8" (20 cm).  
**Beam Width:** 3" (7.6 cm) diameter.  
**Temperature Limits:** Ambient: -40 to 140°F (-40 to 60°C); Process: -4 to 140°F (-20 to 60°C).  
**Temperature Compensation:** -40 to 140°F (-40 to 60°C).  
**Pressure Limits:** 30 psi (2 bar) up to 25°C (77°C). Above 25°C (77°F), rating decreases 1.667 psi per 1°C increase. See pressure and temperature chart.  
**Power Requirement:** 18-28 VDC (two-wire).  
**Output Signal:** 4-20 mA or 20-4 mA (two-wire).  
**Max. Loop Resistance:** 250 Ω at 24 VDC.  
**Electrical Connections:** Screw terminal.  
**Conduit Connection:** 1/2" NPT female (two) or M20.  
**Process Connection:** 2" NPT male or BSPT.  
**Enclosure Rating:** Weather-proof meets NEMA 4X, explosion-proof rated Class I, Div. 1, Groups B, C, D; Class II/III, Div. 1, Groups E, F, G.  
**Mounting Orientation:** Vertical.  
**Failsafe:** On lost echo after 30 s, user selectable to 4, 20, 21, 22 mA or last signal.  
**Memory:** Non-volatile.  
**Display:** 6 character LCD.  
**Units:** In, cm, ft, m, percent.  
**Memory:** Non-volatile.  
**Programming:** 4 button.  
**Weight:** 4.0 lb (1.8 kg).  
**Agency Approvals:** CE, FM.





### Power Supply

The transmitter requires a minimum of 18 Volts DC at its connection for proper operation, and a maximum of 28 Volts. Choose a power supply with a voltage and current rating sufficient to meet this power specification under all operational conditions. If the supply is unregulated, make sure that the output voltage remains within the required voltage range under all power line conditions. Ripple on the supply should not exceed 100 mV.

### Loop Resistance

The maximum allowable loop resistance is dependent on the power supply voltage. The maximum loop voltage drop must not reduce the transmitter voltage below the 18 Volt minimum. The maximum loop resistance can be calculated using the following equation:

$$R_{MAX} = \frac{V_{PS} - 18.0}{20 \text{ mA}}$$

Where  $V_{PS}$  is the power supply voltage.




Figure 4: Electrical wiring diagram

### SETUP & CALIBRATION

Four buttons are provided for all setup and calibration operations. All settings are stored in nonvolatile memory so they will not be lost if the power is removed.




Figure 5: Display and programming buttons

### KEY FUNCTIONS

#### INDEX

Pressing the **INDEX** button advances the display to the next menu item.

#### ENTER

Pressing the **ENTER** button for approximately two seconds will end operating mode and enter programming mode. In programming mode press the **ENTER** button will store the value of menu items once they are changed to a new value.

#### UP

Pressing the **UP** button increments a value in programming.

#### DOWN

Pressing the **DOWN** button decrements a value in programming.

#### UP & INDEX

Pressing the **UP** and **INDEX** simultaneously will allow faster increments in a value for programming.

#### DOWN & INDEX

Pressing the **DOWN** and **INDEX** simultaneously will allow faster decrements in a value for programming.

## MENU SELECTIONS

The transmitter has two modes: operating and programming. In the normal operating mode the transmitter will display the liquid height. The unit comes factory calibrated with the output defaulted to 4 mA equal to the maximum range and 20 mA equal to the minimum range of the transmitter model. In the programming mode the transmitter will display the programming menus and choices. When in the programming mode the transmitter will hold the last current value. The value will not change until the transmitter is returned to operating mode via RUN in the menu structure.

To enter the programming mode press and hold the **ENTER** button for approximately 5 seconds. Once in programming mode there are the following top menu selections: **DISPLAY**, **TANK**, **OUTPUT**, **TARGET CAL**, **VALUES**, **HELP**, and **RUN**. Pressing the **INDEX** button will increment to the next top menu and pressing the **ENTER** button will enter the menu for programming changes.

## DISPLAY MENU

Press **INDEX** to advance to the next menu time. Press **ENTER** to retain the value.

### MEASURE

Sets the transmitter output: Select **LIQUID** or **AIR**. Factory default is **LIQUID**.

**LIQUID** Output will be the height of the liquid in the tank.

**AIR** Output will be the height of the air above the liquid in the tank.

**EXIT** Exit without making changes.

### UNITS

Sets the transmitter display and output unit of measure. Select **INCHES**, **FEET**, **CM**, or **METER**. Factory default is **INCHES**.

**INCHES** Display and output will be in inches.

**FEET** Display and output will be in feet.

**CM** Display and output will be in centimeters.

**METER** Display and output will be in meters.

**EXIT** Exit without making changes.

### SHOW

Sets the transmitter display for distance measure or percentage measure. Select **DISTANCE** or **PERCENT**. Factory default is **DISTANCE**.

**DISTANCE** Display will be in units of distance.

**PERCENT** Display will be in percentage of range.

**EXIT** Exit without making changes.

### HELP

Displays a guide to the menu items in this menu. Press **ENTER** to display.

### EXIT

Exits **DISPLAY** menu and goes back to the top menu. Press **ENTER** to go back to the top menu or press **INDEX** to loop back through the **DISPLAY** menu options.

## TANK MENU

If the tank dimensions are known these menu item can be used to set the 4 and 20 mA points manually. See Figure 6 below. Press **INDEX** to advance to the next menu item. Press **ENTER** to retain the value.

### HEIGHT

Sets the 4 mA value. Program as the distance from the transducer face to the 4 mA value desired (normally the bottom or lowest value of the tank). Factory default is the maximum range of the model. Use the **UP** and **DOWN** buttons to change the value in the length units the unit has been programmed for. The programmed value can be anywhere in the range below **FILL HEIGHT**. If reverse mA is used then this will become the 20 mA value.

### FILL HEIGHT

Sets the 20 mA value. Program as the distance from the **HEIGHT** (normally the bottom of the tank) to the 20 mA value desired. Factory default is the maximum range of the model minus the blind zone distance of 8" (20 cm). Use the **UP** and **DOWN** buttons to change the value in the length units the unit has been programmed for. The programmed value can be anywhere in the range above **HEIGHT**. The maximum value for **FILL HEIGHT** is the maximum range of the unit minus the blind zone distance of 8" (20 cm). The blind zone distance is automatically subtracted from the **FILL HEIGHT** value programmed. If reverse mA is used then this will become the 4 mA value.

### NOTICE

When setting up **HEIGHT** and **FILL HEIGHT** ensure that the minimum **BLIND ZONE** requirements are adhered to with no target within the **BLIND ZONE** and that the **FILL H** is not higher than the **HEIGHT**. If these parameters are not maintained, unit may remain in **WARM UP** mode until the proper levels have been input. If unit is in **WARM UP** ensure no targets are within the **BLIND ZONE** area and cycle power to return to set up to update the set up parameters.




Figure 6: Height and fill height

### HELP

Displays a guide to the menu items in this menu. Press **ENTER** to display.

### EXIT

Exits **TANK** menu and goes back to the top menu. Press **ENTER** to go back to the top menu or press **INDEX** to loop back through the **TANK** menu options.

## OUTPUT MENU

Press **INDEX** to advance to the next menu item. Press **ENTER** to retain the value.

### SAFE MODE

Sets the output of the transducer for fail-safe mode. The transmitter will output the safe mode programmed setting if the transmitter loses the echo signal. Select 22 mA, 21 mA, 20 mA, 4 mA or HOLD. Factory default value is 22 mA. Unit will resume normal operation when echo signal is again received.

- 22 mA** Output of 22 mA.
- 21 mA** Output of 21 mA.
- 20 mA** Output of 20 mA.
- 4 mA** Output of 4 mA.
- HOLD** Output of last known signal is held.
- EXIT** Exit without making changes.

### REVERSE MA

Sets the transmitter output to be forward or reverse acting. Select **NORM** or **REV**. Factory default is **NORM** with 4 mA set at the maximum range of the unit and 20 mA set at the end of the blind zone. See Figure 7 below.

**Note:** **HEIGHT** and **FILL H** must be set before reversing the output.

- NORM** 4 mA is set to be the bottom of the tank (tank empty) and 20 mA is set to be the height the liquid can go in the tank (tank full).
- REVERSE** 20 mA is set to be the bottom of the tank (tank empty) and 4 mA is set to be the height the liquid can go in the tank (tank full).
- EXIT** Exit without making changes.




Figure 7: Reverse output operation

### HELP

Displays a guide to the menu items in this menu. Press **ENTER** to display.

### EXIT

Exits **OUTPUT** menu and goes back to the top menu. Press **ENTER** to go back to the top menu or press **INDEX** to loop back through the **OUTPUT** menu options.

### TARGET CAL MENU

Target Calibration sets the tank empty and tank full distances for the transmitter output based on the actual level in the tank. This is good to use if the tank dimensions are unknown or if it is desired to fill and empty the tank for precise measurement points. Press **INDEX** to advance to the next menu time. Press **ENTER** to retain the value. See Figure 8 below.

### FULL

Fill the tank to the full liquid level desired. Press **ENTER** and this level will be saved.

### EMPTY

Drain the tank to the empty level desired. Press **ENTER** and this level will be saved.

### HELP

Displays a guide to the menu items in this menu. Press **ENTER** to display.

### EXIT

Exits **TARG CAL** menu and goes back to the top menu. Press **ENTER** to go back to the top menu or press **INDEX** to loop back through the **TARG CAL** menu options.




Figure 8: Target calibration

### VALUES MENU

#### SETUP

Displays the current programmed setup for the unit. This is scrolling data that will return to the **VALUES** menu after displaying all the parameters. Values shown are: **MEASUR**, then the setting; **UNITS**, then the setting; **SHOW**, then the setting; **HEIGHT**, then the setting; **FILL H**, then the setting; **SAFE**, then the setting; **REV MA**, then the setting.

#### DIAGNOSTICS

Displays diagnostic items that may be relevant to the transmitter and its performance in the application. This is scrolling data that will return to the **VALUES** menu after displaying all the parameters. Values shown are **RANGE**, then the setting; **TEMP**, then the setting; **ECHO**, then the setting; **POWER**, then the setting; **VER**, then the setting.

#### RESET

Resets the programming to factory default settings.

**YES** Resets the programming to factory default settings.

**NO** Exits without making changes.

#### EXIT

Exits **VALUES** menu and goes back to the top menu. Press **ENTER** to go back to the top menu or press **INDEX** to loop back through the **VALUES** menu options.

#### HELP MENU

Contains contact information for Dwyer Instruments, Inc.

#### **MAINTENANCE & REPAIR**

Other than the controls mentioned in this manual there are no user maintenance adjustments or routine servicing required for this product. The unit is not field repairable and should be returned to the factory if service is required. Disassembly or modifications made by the user will void the warranty and could impair the continued safety of the product. If repair is required obtain a Returned Goods Authorization (RGA) number and send the unit, freight prepaid, to the address below. Please include a detailed description of the problem and conditions under which the problem was encountered.

Dwyer Instruments, Inc.  
Attn: Repair Department  
102 Highway 212  
Michigan City, IN 46360



This symbol indicates waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.