

No. 1 Ana-Digi


Functional Overview:

1. Multi-functional Electronic Watch: Features include hour, minute, second, month, date, day of the week, alarm, second time zone, and stopwatch.
2. LCD Backlight: Features a light delay that automatically turns off after 3 seconds.
3. Alarm & Chime: Includes one set of timed alarms and an hourly chime (hourly time signal).
4. Analog Time: Button-controlled adjustment for the watch hands.




Operating Instructions:

1. **Switching Functions:** Press the "A" button to cycle through the display interfaces. The sequence is: Time, Date, Alarm, Dual Time, Stopwatch.
2. **Date Mode & Weekday:** SU (Sunday), MO (Monday), TU (Tuesday), WE (Wednesday), TH (Thursday), FR (Friday), SA (Saturday)
3. **Backlight & Settings**
Backlight: Tap the "B" button to activate the LCD backlight. It will automatically turn off after 3 seconds.
Enter Settings: Press and hold the "B" button for 3 seconds to enter the item setting mode.



Setting the Date


1. Enter Setting Mode: In Date Mode, press and hold the "B" button for 3 seconds. The month digits will begin to flash. Press the "A" button to adjust the month value.
2. Set Day: Press the "B" button again to switch to the day setting. Press the "A" button to adjust the day value.
3. Set Day of the Week: Press the "B" button once more to switch to the day of the week setting. Press the "A" button to adjust the value.



Stopwatch Timing Mode


Up to 30 minutes.

- Start/Stop:** In Stopwatch mode, press the "B" button to start timing. Press the "B" button again to stop timing.
- Reset:** Press and hold the "B" button for 3 seconds to clear the stopwatch value (reset to zero).
- Exit:** In Stopwatch mode, press the "A" button to return to Timekeeping mode.



Setting Time (or Second Time Zone):

1. In Time Mode, press and hold the "B" button for 3 seconds. The seconds digits will start flashing, indicating you have entered the Time Setting Mode.
2. Press the "B" button again to cycle through: Hours -> Minutes -> 12H/24H Format.
3. Press the "A" button to change/increase the value of the selected item.



Visual Setting Guide:

B Button: Enter Setting Mode

Setting Sequence:

Time Mode -> (Hold B for 3s) -> Seconds -> (Press B) -> Hours -> (Press B) -> Minutes -> (Press B) -> 12/24H Format

•To Adjust: Use the A Button to change values.

•To Cycle: Use the B Button to move to the next setting.

Press B button to finish.

Setting the Analogue Time

- Use an object, such as a pen, to press the button 'C'.
- For Large Adjustments: Press and hold the 'C' key. The hands will move continuously, allowing you to advance the time quickly
- For Precise Alignment: Briefly tap the 'C' key. This moves the hands in small increments, perfect for fine-tuning the exact minute.



GULWATCHES

Delva AB

www.gulwatches.com gul@gulwatches.com