

MANUAL FOR BANNERS

TOP & BOTTOM CLIPS

How to measure the banner file size:


The banner has to be attached inside the truss frame. See example below.

Use an alu list in the sewing line in both top and bottom part of the banner.

The bannersize is the total length of all components.

OBS!

Add for connectors: X-10 = 1cm, X-15 = 2cm and X-20 = 2cm.



MANUAL FOR PRINT FILES

TOP & BOTTOM CLIPS

- Documents All documents need to be delivered as PDF-files.
- Colours Pictures and graphic all in CMYK.
- Pictures The resolution in a 1/1 document is 100 dpi.
If the document is 1/2 the resolution needs to be 200dpi.
- Text, Logo & Graphic All text, logo & graphic elements needs to be vectorized - from eps, ai, pdf-file.
- Bleed 30mm in top and bottom 5mm in each side.

