



# Ændring af telefon nummer eller mail på alerts (alarmer)

Gå på [www.wifi.ecowater.com](https://www.wifi.ecowater.com)



Log på med din mail adresse og det password du bruger på din app.



Klik på view

ECOWATER SYSTEMS® EcoWater.com anita@jyskvandteknik.dk Logout English

JVT 1 AC000W001535746

Anita Graversen Select a system Dashboard Alerts Settings Support

Recharge Now  
Schedule Recharge

### Dashboard

JVT 1 AC000W001535746 GREENLINE 25

Derefter klik på alerts

ECOWATER SYSTEMS® EcoWater.com anita@jyskvandteknik.dk Logout English

JVT 1 AC000W001535746

Anita Graversen Select a system Dashboard Alerts Settings Support

Alerts Log  
Manage Customer Alerts

### Alerts Log

JVT 1 AC000W001535746 GREENLINE 25

Klik på Manage Customer Alerts

ECOWATER SYSTEMS® EcoWater.com anita@jyskvandteknik.dk Logout English

JVT 1 AC000W001535746

Anita Graversen Select a system Dashboard Alerts Settings Support

Alerts Log  
Manage Customer Alerts

### Manage Customer Alerts

JVT 1 AC000W001535746 GREENLINE 25

**Preferred Contact**  
In order to receive email or text message notifications about this system, you must enter a valid cell phone or email address. Check the boxes below to receive a text message or email when your system experiences the following situations.

<b>Cell Phone(s) *</b>	<b>Email Address(es) ^</b>
<input type="text" value="45"/> <input type="text" value="28193901"/>	<input type="text"/>
<input type="text" value="+1"/>	

Nu kan du taste nyt telefonnummer i rubrikken eller ændre mail, såfremt det er denne, du bruger. Klik derefter på "save" i bunden af siden.

Nu er ændringen trådt i kraft.