


**SÅDAN SKIFTER DU SIKRINGEN HVIS STRØMMEN ER GÅET PÅ DIT VÆRELSE (GÆLDER IKKE GULVKONTAKTEN DER SKAL DU KONTAKTE KONTORET I ÅBNINGSTIDEN)**

**HOW TO CHANGE THE FUSE IF THE POWER HAS GONE OUT IN YOUR ROOM (DO NOT APPLY TO THE FLOOR SWITCH THERE YOU NEED TO CONTACT THE OFFICE DURING OPENING HOURS)**



**SIKRINGERNE LIGGER OVEN PÅ SIKRINGSBOKSEN I KØKKEN B, OG GØR KUN SOM BESKREVET NEDENFOR:**

1. SLUK PÅ KONTAKTEN TIL DEN GRUPPE DER HØRER TIL DIT VÆRELSE
2. SKUB SIKRINGSHOLDEREN UD OG TAG SIKRINGEN UD AF DENNE, SÆT EN NY SIKRING I, BEMÆRK AT DER ER FORSKEL PÅ 10 Amp & 16 Amp.
3. SKUB SIKRINGSHOLDEREN IND IGEN
4. TÆND FOR KONTAKTEN IGEN
5. HVIS DETTE IKKE LØSER PROBLEMET, KONTAKT BEBOERRÅDET PÅ [br@rsk.dk](mailto:br@rsk.dk)

**THE FUSES ARE LOCATED ON TOP OF THE FUSE BOX IN KITCHEN B, AND DO ONLY AS DESCRIBED BELOW:**

1. TURN OFF CONTACT WITH THE GROUP BELONGING TO YOUR ROOM
2. PUSH THE FUSE HOLDER AND REMOVE THE FUSE FROM IT, INSERT A NEW FUSE, NOTE THAT THERE IS A DIFFERENCE BETWEEN 10 Amp & 16 Amp.
3. UNSCREW THE FUSE HOLDER
4. PUSH THE SWITCH BACK IN
5. IF THIS DOES NOT SOLVE THE PROBLEM, CONTACT THE RESIDENTS' COUNCIL AT [br@rsk.dk](mailto:br@rsk.dk)

09. June 2021

Peter Foldager Overgaard, Inspektør