

Superbruger 2

Indstillings- menuer

*Hvordan man kan ændre
de grundlæggende indstillinger*

**SKLA dias- og negativscanner
NORITSU LS-1100**

Version 1.0 – 2024-09-20

Indstillinger i Noritsu LS-1100

Fra Control Main Display kan der tilgås rigtig mange funktioner til indstilling af scanner og miljøet omkring den. Tryk på F nederst til venstre og menu vises.

Nedenstående indstillinger er ikke noget der skal gøres til daglig, men det kan være fint at vide, hvor der kan ændres på de grundlæggende indstillinger.

The image shows the M5001 Controller Main Display interface. At the top, there's a status bar with fields for Status, Delivery Time Judgment, PRINT, MEDIA, Order, Quantity, Paper, and Output device. The main display area shows a large black screen with a play button icon in the top left corner, indicating a video or image is being processed. The date and time are 11-07-2024 14:57. The order number is 00000106 and the printer model is Noritsu-EZC. On the right side, there are control buttons for Output Media, Top, Information Start, Pause, Bottom, Interrupt, and Delete. At the bottom, there are buttons for Proceeding... and Processed, and a Number of Orders field showing 1. A large green START STOP button is located on the right side of the bottom panel. The bottom status bar shows Total Print Counts (0000000000) and HD free space (402.7GB). A button labeled 'F' is located at the bottom left.

The Functions menu is displayed on the left side, listing various options:

- Start Up Checks
- Daily Setup
- Process result information
- Management Tool
- Printer setting
- Tool
- Close Down Checks
- Mail
- Version Information
- Quit The Application
- Back

The Management Tool window is open on the right side, showing a list of settings:


- System management
- Operator Selections
- Print Channel
- System setting
- Option
- Input Media
- Output Media
- Printer setting
- Network terminal setting
- Service setting
- Price Setting
- Photo Retouch Module setting
- Image Processing Setting
- Data management
- Password Registration
- Error Record

The Management Tool window also shows the Display Number [5100 - 00] and the time 14:00. An End button is visible at the bottom right of the Management Tool window.

Liste over scannerindstillinger

No.	Channel Name	Input Media Type	Template	Print Size	Name
001	JPEG auf HDD	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
002	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
003	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
004	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
005					
006					
007	TIFF auf HDD	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
008	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
009	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
010	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
011					
012					
013	TIFF (16bit) auf HDD	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
014	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
015	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
016	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
017					
018					
019					
020	JPEG auf CD	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
021	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
022	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
023	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
024					
025					
026	TIFF auf CD	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
027	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
028	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
029	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
030					
031					
032	TIFF (16bit) auf CD	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
034	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
035	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
036					
037					
038					
039					
040	JPEG auf DVD-R	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
041	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
042	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
043	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
044					
045					
046	TIFF auf DVD-R	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
047	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
048	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
049	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
050					
051					
052	TIFF (16bit) auf DVD-R	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
053	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
054	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
055	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
056					
057					
058					
059					
060	JPEG auf USB	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
061	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
062	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
063	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
064					
065					
066	TIFF auf USB	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
067	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
068	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
069	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
070					
071					
072	TIFF (16bit) auf USB	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
073	Low 1512x1002px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
074	Mid 3024x2005px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
075	High 6048x4011px	Color (Neg)	- / - / -	203(1)x305.0 / 203(1)x 82.5 / 203(1)x 82.5	//
076					
077					
078					

Herunder mange af de enkelte skærbilleder der kan tilgås.



Input media

Indstilling af hvilke medier der skal kunne hentes data fra. I vores tilfælde, skal der kun kunne vælges scanneren.

F -> System management → Input media

Fjern alle flueben, bortset fra "01 Film scanner"

No.	Input Media	Drive
<input checked="" type="checkbox"/>	01 Film Scanner	
<input type="checkbox"/>	02 Flatbed Scanner	
<input type="checkbox"/>	03 FD	-
<input checked="" type="checkbox"/>	04 DVD-ROM(±R/RW)	E
<input type="checkbox"/>	05 DVD-RAM	-
<input checked="" type="checkbox"/>	06 CD-ROM (CD-R/RW)	E
<input type="checkbox"/>	07 Compact Flash	-
<input type="checkbox"/>	08 SmartMedia	-
<input type="checkbox"/>	09 PC Card	-
<input checked="" type="checkbox"/>	10 HD	C
<input type="checkbox"/>	11 SD Card	F
<input type="checkbox"/>	12 Memory Stick	-
<input checked="" type="checkbox"/>	13 USB Flash Memory	F
<input type="checkbox"/>	14 DPEgg	-
<input type="checkbox"/>	15 xD-Picture Card	-
<input type="checkbox"/>	16 miniSD Card	-
<input type="checkbox"/>	17 Memory Stick Duo	-
<input type="checkbox"/>	18 RSMMC	-

Detail Setting

Input Device: Film Scanner

Machine Type Name: LS-1100

IX Data Settings

Environment

Maintenance

OK Back

EZ Publisher Utility Display Number [M5080]

No.	Service Name	Device	Drive
1	HDD	Hard Disk Drive	C
2	CD-JPEG	CD-R/RW	E
3	JPEG-HDD	Hard Disk Drive	C
4	TIFF-HDD	Hard Disk Drive	C
5	TIFF(16bit)-HDD	Hard Disk Drive	C
6	CD-TIFF	CD-R/RW	E
7	CD-TIFF(16bit)	CD-R/RW	E

Service Name:

Buttons: Addition Update Delete

Service setting | Output Image Setting | Print Setting | Writing Setting

Device:

Drive:

Media Type:

Save in multiple media

Maximum number of images saved in a media

Save equal number of images in each media

Buttons: Version Information Back

EZ Publisher Utility Display Number [M5080]

No.	Service Name	Device	Drive
8	DVD-JPEG	DVD-R	E
9	DVD-TIFF	DVD-R	E
10	DVD-TIFF(16bit)	DVD-R	E
11	USB-JPEG	USB Flash Memory	F
12	USB-TIFF	USB Flash Memory	F
13	USB-TIFF(16bit)	USB Flash Memory	F

Service Name:

Buttons: Addition Update Delete

Service setting | Output Image Setting | Print Setting | Writing Setting

Device:

Drive:



Media Type:



Save in multiple media



Maximum number of images saved in a media



Save equal number of images in each media



Buttons: Version Information Back


































Operator Selections Display Number [5120 - 00]

Input operation | Display/Operation | Additional | Front | Index | CVP Imprint Setting | Order management | Preview Display | Pricing Sheet Print | SPC

240

Date+Time+Title Imprinting Selection


Imprinting User Advice (Camera Data)

Media


DTM+FID+CMT DPOF Printing Specification

None Exif Printing Specification

Front Print Letter Color

Light Blue  Color Creation/Color Change

Edge Color of Front Print Character

Light Blue  Color Creation/Color Change

Standard Front Print Font Size

None Background Color of Front Print Text

Arial Font for front print

OK Back

Operator Selections Display Number [5120 - 00]

Input operation | Display/Operation | Additional | Front | Index | CVP Imprint Setting | Order management | Preview Display | Pricing Sheet Print | SPC

Operator Selections Display Number [5120 - 00]

Input operation | Display/Operation | Additional | Front | Index | CVP Imprint Setting | Order management | Preview Display | Pricing Sheet Print | SPC

Print Operation

Automatic Order number input method

In order of priority How to process orders

by Order Designation of printers

Delivery/Finish Time

Setting Make settings for Delivery/Finish time.

Save

C: Image save location

40 GB Image save capacity

20 GB Image protect capacity

Auto delete

2 day(s) Image save period

Saving Passed Images

OK Back

Operator Selections Display Number [5120 - 00]

Input operation | Display/Operation | Additional | Front | Index | CVP Imprint Setting | Order management | Preview Display | Pricing Sheet Print | SPC

Preview Display (Media)

sec Display interval

Auto Printing Start

 Print Method

OK Back

Operator Selections Display Number [5120 - 00]

Input operation | Display/Operation | Additional | Front | Index | CVP Imprint Setting | Order management | Preview Display | Pricing Sheet Print | SPC

 Printing of Pricing Sheet Print

 Background Color

Print(s) Pricing Sheet Print Counts

Pricing Sheet Image Part

 Paper Fitting

Price sheet header

Price sheet free printing area

 First Line

 Second Line

 Third Line

Price sheet setting for media copy

CH Channel to use

OK Back

