



# User manual


## MossRider M102

Patenteret, CE-marked  
2012 rev. 22



Grease with chain oil every hour and after use.

Lubricate greasenipples every 2 hours.



### Adjusting the working depth:

1. Mount MossRider after the garden tractor on a level surface.
2. Put the MossRider in the operating position and stretch the adjusting rod by pressing down on the lifting handle.
3. Turn the adjusting rod until the rear row of stars is approximately 15mm above the ground.  
If the lawn is hard, the distance can be adjusted a little less.  
If the lawn is soft or the garden tractor cannot pull, adjust the distance more.  
The wheels must not touch the lawn during operation.

### Troubleshooting:

- Problem: Stars go tight even if chains and shafts are lubricated.  
The chain is very tight.
- Solution: A hard layer of soil has built up between the teeth on the gears, so the chain does not fall down between the teeth. This coating is most easily removed with a screwdriver.