

BG Diesel Oil Change Services

BG on the Road[®]

Complimentary Roadside Assistance

Services Provided:

- Towing Assistance*
- Tire Change Assistance
- Jump Start Assistance
- Fuel and Fluid Delivery**
- Rental Car Reimbursement
- Lock-Out Service**
- Theft/Hit and Run Protection
- Travel Discount Service
- Emergency Travel Expenses
- Travel Discount Service

*towing available for accidents and vehicle disablements.
**cost of gas, other fluids or key replacement not included.

Up to \$100 USD per event, except for emergency travel expense of \$300 USD and theft/hit and run protection of \$500 USD. (up to two occurrences)

Duration: 6 months.

Lifetime BG Protection Plan

BG Protection Plan

For Engine & Fuel System

Initial Qualification:
Under 75,000 miles/120,000 km.

Renewable for the lifetime of the vehicle.

• Engine Protection:


Oil Change with BG DOC[®] must be performed at least every 7,500 miles/12,000 km.

All services include the Roadside Assistance and the Protection Plan for qualified vehicles.

Ask your Service Advisor for complete details.

Basic

- ✓ Drain old engine oil and install BG DOC[®] Diesel Oil Conditioner with new engine oil
- ✓ Install new oil filter
- ✓ Lubricate chassis
- ✓ Top-off fluids, perform maintenance check



Premier

- ✓ Drain old engine oil and install BG DOC[®] Diesel Oil Conditioner with new engine oil
- ✓ Install new oil filter
- ✓ Install BG 244[®] in the fuel system for deposit control
- ✓ Lubricate chassis
- ✓ Top-off fluids, perform maintenance check



Performance

- ✓ Install BG EPR[®] in the crankcase to remove contaminants, free piston rings and restore compression
- ✓ Air-purge old engine oil from the system
- ✓ Prime all engine passages with fresh, new oil
- ✓ Install BG DOC[®] Diesel Oil Conditioner with new engine oil
- ✓ Install new oil filter
- ✓ Install BG 244[®] for fuel system
- ✓ Lubricate chassis
- ✓ Top-off fluids, perform maintenance check

