



SEAT ADJUSTMENTS:

1. Base plate
2. Rotating mechanism
3. Horizontal vibration isolator
4. Longitudinal movement adjustment
5. Seat extension adjustment
6. Seat height adjustment
7. Seat tilt adjustment
8. Seat suspension adjustment
9. Lumbar and side contour adjustment
10. Backrest tilt adjustment
11. Right/left armrest - adjustable, fully foldable
12. Adjustable headrest
13. Fast release button

SITZEINSTELLUNGEN:

1. Bodenplatte
2. Drehmechanismus
3. Schwingungsisolator
4. Einstellung der Längsbewegung
5. Sitzkissenverstellung
6. Sitzhöhenverstellung
7. Einstellung der Sitzneigung
8. Einstellung der Federung des Sitzes
9. Lordose und seitliche Konturanpassung
10. Neigungsverstellung der Rückenlehne
11. Rechte/linke Armlehne - verstellbar, vollständig klappbar
12. Einstellbare Kopfstütze
13. Schnellabsenkungstaste