

The See Snake I-Connector makes it possible to extend or repair the LED-Strip by cutting it and add pins to it.




ACCESSORIES

I-CONNECTOR

Instruction manual




1 To extend




Find the blank space




Cut




The copper wire core




Insert pin



Press it in




Insert the ends with the mounted pins into the I-CONNECTOR.




Assembled


2 Extend or repair




Cut the defective part off by cutting at the blank space which are placed one pr. 1 meter.



PLEASE NOTE! If the defective part is only 50 cm long, you still need to cut 1 meter



Use a new strip and joint the I-CONNECTOR to each strip



To prevent water from entering the joints - finish with glue to seal any gaps



WARNING!

**DO NOT POWER ON
WHEN REPLACING!**