

Nr 1. Siko bred (mm) 25, 30, 35, 40*, 45*, 50*

ABCDEFGHIJKLMN
OPQRSTUVWXYZ
012345678

Nr 2. Herrgård (mm) 25, 30, 35, 40, 45*, 50*, 55, 65*, 80*

ABCDEFGHIJKLMN
OPQRSTUVWXYZ
012345678

Nr 3. Block (mm) 12, 20, 25, 30, 35, 40, 50, 60, 70, 80, 100, 120, 150

ABCDEFGHIJKLMNOPQR
STUVWXYZ
012345678

Nr 4. Block smal (mm) 25, 30, 40, 50

ABCDEFGHIJKLMNOPQRSTUVWXYZ

Nr 5. Block Fasett (mm) 11, 15, 23, 29, 34, 40, 48, 54, 69, 80

ABCDEFGHIJKLMNOPQRS
TUVWXYZ
012345678

(* finns ej i siffror)

Nr 6. Fransk Antikva (mm) 25, 30, 35, 40, 45, 50, 55, 63*

ABCDEFGHIJKLMN
OPQRSTUVWXYZ
012345678

Nr 7. Antikva (mm) 25, 30, 35, 40, 45*, 50*, 56*, 60*, 70*, 100, 150

ABCDEFGHIJKLMN
OPQRSTUVWXYZ
012345678

Nr 8. AT (mm) 25, 30, 35, 40*, 45*, 50*

ABCDEFGHIJKLMN
OPQRSTUVWXYZ
012345678

Nr 9. RE (mm) 25, 30, 35, 40, 45*

ABCDEFGHIJKLMN
OPQRSTUVWXYZ
012345678

(* finns ej i siffror)

Nr 10. Slott (mm) 15, 20, 25, 30, 35, 40, 45*, 50*, 60*, 70*

A B C D E F G H I J K L M N O
P Q R S T U V W X Y Z
0 1 2 3 4 5 6 7 8

Nr 11. Skrivstil Classic (mm) 45/20, 55/30

Skrivstil Classic
0 1 2 3 4 5 6 7 8

Nr 12. Skrivstil (mm) 45/27

A B C D E F G H I J K L
M N O P Q R S T U V
W X Y Z
a b c d e f g h i j k l m n o p q
r s t u v w x y z
0 1 2 3 4 5 6 7 8

(* finns ej i siffror)