



H. HIGH BEAM INDICATOR LAMP  
 T INDICATOR WARNING LAMP  
 N NEUTRAL INDICATOR LAMP

HEADLAMP  
 PARKING LAMP  
 LH FRONT INDICATOR

RH FRONT INDICATOR  
 SPEEDOMETER  
 TACHOMETER

SEE NOTE 1  
 ENGINE KILL SWITCH  
 STARTER SWITCH

SEE NOTE 1  
 HORN  
 STARTER MOTOR  
 SEE NOTE 2  
 ENGINE KILL SWITCH  
 SEE NOTE 1  
 FRONT BRAKE LIGHT SWITCH

SEE NOTE 1  
 IGNITION COIL  
 STARTER RELAY  
 BATTERY  
 STOP LAMP SWITCH

FLYWHEEL GENERATOR  
 NEUTRAL SWITCH

IGNITION SWITCH

OFF	B/Y	B/W	R	0	Br	Br(Gr)
ON						
P						

DIP SWITCH

H	W	Y	Y/W

PASSING SWITCH

OFF	0	Gr	Y/W	Bl/W	W	W/R	W/G
ON							

INDICATOR SWITCH

	R	B	Bl	Lg

HORN SWITCH

CDI UNIT

REGULATOR/RECTIFIER

INDICATOR RELAY

- NOTES**
1. GT 200 ONLY
  2. GT 250 ONLY
  3. GREY ON GT 200
  4. BLACK/RED ON GT 250
  5. GREEN ON GT 250

Wiring diagram - GT250 X7 and GT200 X5