
DVT LIGHT

Menu Structure

MB-8



Level 1	Level 2	Level 3	Function
Mode		---	Activate the different DMX modes
Test	Test All	---	Tests all colors
	Test Red	---	Tests Red color
	Test Green	---	Tests Green color
	Test Blue	---	Tests Blue color
	Test White	---	Tests White color
Info	DMX	ADR	Info about all DMX channels
	Sensors	Sensors	Info about Main board- and Humidity sensors
	Wireless Info	CRMX	Info screen for wireless function
	Software Version	Software Version	Info about current software version
Manual	Static Color	Red	Manual control of red color
		Green	Manual control of green color
		Blue	Manual control of blue color
		CTC	Manual control of CTC
		Diffuser	Manual control of diffuser
	Static Cinema	Dimmer	Manual control of dimmer
		Fan	Manual control of fan (Not implemented yet)
		Diffuser	Manual control of diffuser
		CTC	Manual control of CTC
		CTC DUV	Manual control of CTC DUV
		GEL	Manual control of GEL
		Macro	Manual control of Macro
		Red	Manual control of red color
		Green	Manual control of green color
		Blue	Manual control of blue color
Settings	Factory Default	Factory Default	Activation of factory default settings
	Wireless	Unlink	Unlink wireless DMX
		DMX Enable	Enable wireless DMX
		DMX Disable	Disable wireless DMX
	Startup Mode	Off	Choose Off as startup mode
		Static Color	Choose Static Color as startup mode
		Static Cinema	Choose Static Cinema as startup mode
	DMX Lost	Blackout	Choose Blackout when DMX is lost
		Static Color	Choose Static Color when DMX is lost
		Hold	Choose Hold DMX values when DMX is lost
		Static Cinema	Choose Static Cinema when DMX is lost
	Display	Orientation	Normal Display orientation
			Flip Display orientation
		Backlight	Level Manual control of backlight
	Soft Dimming	On	Provides smoother brightness adjustments. (Default)
		Off	Uses standard brightness control.
	Service Menu	Service Menu Pin	Set pin for Service menu, to access service parameters

DVT LIGHT

Birkegaardsvej 36D

8361 Hasselager

Denmark

+45 48 80 38 36

sales@dvtlight.com

www.dvtlight.com



Rev: 26/9/2025 Valid from SW version 0.16