



## Place in Site Master File #10

### Instruction for temperature logger

There will be a disposable temperature logger (TempTale4) inside the packages you receive with IMP and placebo. Inside the package you will also find a document entitled "The reading of TempTale4 temperature logger". Please read the document and follow the instructions carefully.

The reading of TempTale4 temperature logger (top half of the document)

TT4 no:	Protocol:	Site:
<p>Follow the instructions to read the TT4 USB logger</p>		
<ul style="list-style-type: none"> <li>- Stop the TempTale4 logger by pressing down the stop button for 3 seconds (The "Sun" disappears and a "Stop" appears)</li> <li>- Check if the logger shows an alarm. (If a bell is visible in the display under the "Stop".</li> </ul>		
<p><b>Important: If the logger shows an alarm, the study medication must be placed in QUARANTINE. Please leave the study medication in quarantine until further notice.</b></p>		
<ul style="list-style-type: none"> <li>- If the TT4 does not show an alarm the logger device can be discarded after the result has been send to Nomeco</li> </ul>		
<p><b>Send the logger data to Nomeco:</b></p>		
<ul style="list-style-type: none"> <li>- Put the USB device in the computer and a window with two files will appear. A pdf file and a ttx file.</li> <li>- In the pdf file there is a summary of the temperature curve. The ttx file can only be opened by Nomeco A/S.</li> <li>- Please send both files to Nomeco A/S: <a href="mailto:ctsm@nomeco.dk">ctsm@nomeco.dk</a>.</li> </ul>		

**IF** the logger data cannot be downloaded by your computer then – and only then – fill in the bottom half of the document (shown on page 2).

The reading of TempTale4 temperature logger (bottom half of the document)

**Fill in the below ONLY if the logger data can not be downloaded by the computer**

- If it's not possible to download the data then press down the stop button for 3 seconds and 5 successive numbers will appear. Please note the numbers in the table below.

**Data results:**

Digit no.1:Mean temperature (°C)	
Digit no.2:Highest temperature (°C)	
Digit no.3:Total time above high temperature limit (min)	
Digit no.4:Lowest temperature (°C)	
Digit no.5:Total time below low temperature limit (min)	

Recipient (Name, date)	
------------------------	--

If there is an alarm and the data can't be send to Nomeco by email then send the logger to Nomeco at the following address:

Nomeco A/S  
Att. CTSM  
Borgmester Christiansens Gade 40  
1790 Kbh. V

The TempTale4 temperature logger is disposable.

Please call CRIC at +45 35 45 71 67 for further help to handle the temperature logger.