
# CONGRATULATIONS


to the purchase of your new professional switch mode battery charger. This charger is included in a series of professional chargers from CTEK SWEDEN AB and represents the latest technology in battery charging.



\* Supply plugs may differ to suit your wall socket.

# CHARGING

- 1. Connect the charger to the battery.
- 2. Connect the charger to the wall socket. The power lamp will indicate that the mains cable is connected to the wall socket. The error lamp will indicate if the battery clamps are incorrectly connected. The reverse polarity protection will ensure that the battery or charger will not be damaged.
- 3. Press the MODE-button to select charging program.
- 4. Follow the 8-step display through the charging process. The battery is ready to start the engine when STEP 4 is lit. The battery is fully charged when STEP 7 is lit.
- 5. Stop charging at any time by disconnecting the mains cable from the wall socket.



# CHARGING PROGRAMS

Settings are made by pressing the MODE-button. After about two seconds the charger activates the selected program. The selected program will be restarted next time the charaer is connected.

#### The table explains the different Charging Programs:

Program	Battery Size (Ah)	Explanation	Temp range
5 5	1.2-14Ah	<b>Small battery program</b> 14.4V/0.8A Use for smaller batteries.	<b>-20°C-+50°C</b> (-4°F-122°F)
Ŭ	14-160Ah	Normal battery program 14.41/5A Use for WET batteries, Ca/Ca, MF, GEL batteries and many AGM batteries.	+5°C-+50°C (41°F-122°F)
**	14-160Ah	Cold weather program 14.7V/5A Use for charging at low tempera- tures and for power AGM batter- ies like Optima and Odyssey.	-20°C-+5°C (-4°F-41°F)
RECOND	14-160Ah	Recond program 15.8V/1.5A Use to return energy to the empty WET and Ca/Ca batteries. Recond your battery once per year and after deep discharge to maximise lifetime and capacity. The Recond program adds STEP 6 to the normal battery program. Frequent use of the Recond program may cause water loss in the batteries and reduce service life of electronics. Contact your vehicle and battery supplier for advice.	-20°C-+50°C (-4°F-122°F)

## **ERROR LAMP**

If the error lamp is lit, check the following:



1. Is the chargers positive lead connected to the battery's positive pole?

## 2. Is the charger connected to a 12V battery?

3. Has charging been interrupted in STEP 1, 2 or 5? Restart the charger by pressing the MODE-button. If charging is still being interrupted, the battery... STEP 1: ...is seriously sulphated and may need to be

replaced.

- STEP 2: ... can not accept charge and may need to be replaced.
- **STEP 5:** ...can not keep charge and may need to be replaced.

# **READY TO USE**

The table shows the estimated time for empty battery to 80% charge



BATTERY SIZE (Ah)	TIME TO 80% CHARGED
2Ah	2h
8Ah	8h
20Ah	4h
60Ah	12h
110Ah	26h

## **CHARGING PROGRAM**

	DESULPHATION	SOFT START	BULK	ABSORPTION	ANALYSE	RECOND	FLOAT	PULSE
VOLTAGE (V)							]	
CURRENT (A)			3			6	7	
	15.8V	5A until 12.6V	Increasing voltage to 14.4V 5A	14.4V Declining current	Checks if voltage drops to 12V		13.6V 5A	12.7V-14.4V 5-2A
6	15.8V	0,8A until 12.6V	Increasing voltage to 14.4V 0.8A	14.4V Declining current	Checks if voltage drops to 12V		13.6V 0.8A	12.7V-14.4V 0.8-0.4A
*	15.8V	5A until 12.6V	Increasing voltage to 14.7V 5A	14.7V Declining current	Checks if voltage drops to 12V		13.6V 5A	12.7V-14.7V 5-2A
RECOND	15.8V	5A until 12.6V	Increasing voltage to 14.4V 5A	14.4V Declining current	Checks if voltage drops to 12V	Max 15.8V 1.5A	13.6V 5A	12.7V-14.4V 5-2A
Limit:	Max 8h	Max 8h	Max 20h	Max 10h	3 minutes	30 min or 4h depending on battery voltage	10 days Charge cycle restarts if voltage drops	Charge cycle restarts if voltage drops

#### **STEP 1 DESULPHATION**

Detects sulphated batteries. Pulsing current and voltage, removes sulphate from the lead plates of the battery restoring the battery capacity.

#### **STEP 2 SOFT START**

Tests if the battery can accept charge. This step prevents that charging proceeds with a defect battery.

## STEP 3 BULK

Charging with maximum current until approximately 80% battery capacity.

#### **STEP 4 ABSORPTION**

Charging with declining current to maximize up to 100% battery capacity.

#### **STEP 5 ANALYSE**

Tests if the battery can hold charge. Batteries that can not hold charge may need to be replaced.

## **STEP 6 RECOND**

Choose the Recond program to add the Recond step to the charging process. During the Recond step voltage increases to create controlled gassing in the battery. Gasing mixes the battery acid and gives back energy to the battery.


## STEP 7 FLOAT

Maintaining the battery voltage at maximum level by providing a constant voltage charge.

#### **STEP 8 PULSE**

Maintaining the battery at 95–100% capacity. The charger monitors the battery voltage and gives a pulse when necessary to keep the battery fully charged.

## CONNECT AND DISCONNECT THE CHARGER TO A BATTERY



#### INFO

If the battery clamps are incorrectly connected, the reverse polarity protection will ensure that the battery and charger are not damaged.

# For batteries mounted inside a vehicle

1. Connect the red clamp to the battery's positive pole.

2. Connect the black clamp to the vehicle chassis remote from the fuel pipe and the battery.

3. Connect the charger to the wall socket

 Disconnect the charger from the wall socket before disconnecting the battery
 Disconnect the black clamp before the red clamp.

#### Some vehicles may have positively earthed batteries.

 Connect the black clamp to the battery's negative pole.

2. Connect the red clamp to the vehicle chassis remote from the fuel pipe and the battery.

3. Connect the charger to the wall socket


 Disconnect the charger from the wall socket before disconnecting the battery
 Disconnect the red clamp before the black clamp.

## **TECHNICAL SPECIFICATIONS**

ILCINICAL SPE	
Charger model	MXS 5.0
Model number	1049
Rated Voltage AC	220-240VAC, 50-60Hz
Charging voltage	🏍 🛱 14.4V, 🕸 14.7V, RECOND 15.8V
Min battery voltage	2.0V
Charging current	5A max
Current, mains	0.65A rms (at full charging current)
Back current drain*	<1Ah/month
Ripple**	<4%
Ambient temperature	-20°C to +50°C, output power is reduced automatically at high temperatures
Charger type	Eight step, fully automatic charging cycle
Battery types	All types of 12V lead-acid batteries (WET, MF, Ca/Ca, AGM and GEL)
Battery capacity	1.2–110Ah up to 160Ah for maintenance
Dimensions	168 x 65 x 38mm (L x W x H)
Insulation class	IP65
Weight	0.6kg

\*) Back current drain is the current that drains the battery if the charger is not connected to the mains. CTEK chargers has a very low back current.

\*) The quality of the charging voltage and charging current is very important. A high current ripple heats up the battery which has an aging effect on the positive electrode. High voltage ripple could harm other equipment that is connected to the battery. CTEK battery chargers produce very clean voltage and current with low ripple.



## SAFETY

- The charger is designed for charging 12V lead-acid batteries 1.2-160Ah. Do not use the charger for any other purpose.
- Check the charger cables prior to use. Ensure that no cracks have occurred in the cables or in the bend protection. A charger with damaged cables must not be used. A damage cable must be replaced by a CTEK representative.
- Never charge a damaged battery.
- Never charge a frozen battery.
- Never place the charger on top of the battery when charging.
- Always provide for proper ventilation during charging.
- Avoid covering the charger.
- A battery being charged could emit explosive gasses. Prevent sparks close to the battery. When batteries are reaching the end of their lifecycle internal sparks may occur.
- All batteries fail sconer or later. A battery that fails during charging is normally taken care of by the chargers advanced control, but some rare errors in the battery could still exist. Don't leave any battery during charging unattended for a longer period of time.
- Ensure that the cabling does not jam or comes into contact with hot surfaces or sharp edges.
- Battery acid is corrosive. Rinse immediately with water if acid comes into contact with skin or eyes, seek immediate medical advice.
- Always check that the charger has switched to STEP 7 before leaving the charger unattended and connected for long periods. If the charger has not switched to STEP 7 within 50 hours, this is an indication of an error. Manually disconnect the charger.
- **Batteries consume** water during use and charging. For batteries where water can be added, the water level should be checked regularly. If the water level is low add distilled water.
- This appliance is not designed for use by young children or people who cannot read
  or understand the manual unless they are under the supervision of a responsible person
  to ensure that they can use the battery charger safely. Store and use the battery charger
  out of the reach of children, and ensure that children cannot play with the charger.
- Connection to the mains supply must be in accordance with the national regulations for electrical installations.

# LIMITED WARRANTY

CTEK SWEDEN AB, issues this limited warranty to the original purchaser of this product. This limited warranty is not transferable. The warranty applies to manufacturing faults and material defects for 5 years from the date of purchase. The customer must return the product together with the receipt of purchase to the point of purchase. This warranty is void if the battery charger has been opened, handled carelessly or repaired by anyone other than CTEK SWEDEN AB or its authorised representatives. One of the screw holes in the bottom of the charger is sealed. Removing or damaging the seal will void the warranty. CTEK SWEDEN AB makes no warranty other than this limited warranty and is not liable for any other costs other than those mentioned above, i.e. no consequential damages. Moreover, CTEK SWEDEN AB is not obligated to any other warranty other than this warranty.

## SUPPORT

CTEK offers a professional custom support: **www.ctek.com**. For latest revised user manual see www.ctek.com. By e-mail: **info@ctek.se**, by telephone: +46(0) 225 351 80, by fax +46(0) 225 351 95. By mail: CTEK SWEDEN AB, Rostugnsvägen 3, SE-776 70 VIKMANSHYTTAN, SWEDEN.

VIKMANSHYTTAN, SWEDEN 2010-05-01

Jarl Uggla, President CTEK SWEDEN AB

## CTEK PRODUCTS ARE PROTECTED BY

Patents	Designs	Trade marks
EP1618643	RCD 000509617	CTM TMA669987
SE525604	US D571179	CTM 844303
US7541778B2	US D575225	CTM 372715
EP1744432 pending	US D581356	CTM 3151800
EP1483817 pending	US D580853	CTM 405811
SE524203	RCD 321216	CTM 1461716 pending
US7005832B2	RCD 200830199948X pending	
EP1716626 pending	RCD 000911839	
SE526631	RCD 081418	
US-2006-0009160-A1 pending	US D29/319135 pending	
EP1903658 pending	RCD 001119911	
EP1483818	RCD 321197	
US7629774	RCD 321198	
SE528232	RCD 200830120183.6 pending	
EP09170640.8 pending	ZL200830120184.0	
US12/564360 pending	RCD 000835541	
EP09180286.8 pending	US D596125	
US12/646405 pending	US D596126	

2010-01-27