











CHARACTERISTICS


- body made from high quality stainless steel
- · high forced convection output
- rapid room heating
- · heating also when the fan is off
- low electricity consumption
- safe 12V DC voltage
- contains own microprocessor-controlled unit
- · also suitable for heat pump
- electronically commutated (EC) motor

DIMENSIONS


width - with standard frame	303 mm
width - with covering frame	329 mm
height	125 mm
length	900 - 3000 mm
connection *	G1/2"


^{*} internal thread on the heat-exchanger, without water connection accessories

CROSS SECTION



LONGITUDINAL SECTION





FRAMES

Standard frame (AL-aluminium)



Covering frame (AL-aluminium)





GRILLES - materials




(shades of the grilles are only illustrative)


GRILLES - profile





• st.steel-rolling-sparse1)





1) the grille must be ordered with the convector due to the modification of the convector construction

Standard grilles are transverse, if you are interested in **LONGITUDINAL GRILLES**, please contact your sales representative.

Convectors are designed to the CONCRETE FLOOR, in case of HOLLOW FLOOR installation, please consult with your sales representative.

The standard delivery includes convector and anchoring accessories. All other accessories (grille, connection accessories, control elements, etc.) must be ordered and specified separately.

As a part of the product development, MINIB, a.s. reserves the right of construction and price adjustments.

MINIB[®]


+420 731 152 133

export@minib.cz

www.minib.com



ORIENTATION AND CONNECTION OF THE CONVECTOR



If the convector is used as an additional heat source which prevents the condensation of the window (exchanger position at the window side), please consult with your sales representative. Combination of the exchanger position (room side/window side), convector type (left/ right) and water connection (straight/corner) must be specified with the order of the convector.

HEATING OUTPUT

heating output Q [W]						
		speed				
length L	input / output	speed 0	speed 1	speed 2	speed 3	
[mm]	water tempe- rature [°C]	air temperature tA = 20°C				
	85/75	170	1136	1251	1476	
09 = 900	75/65	140	934	1029	1213	
	65/55	110	735	810	955	
	45/40	59 199	397	437 1460	515 1721	
	85/75 75/65	163	1326 1090	1200	1416	
10 = 1000	65/55	129	858	945	1114	
	45/40	69	463	509	601	
	85/75	270	1799	1981	2336	
	75/65	222	1479	1629	1921	
12 = 1250	65/55	175	1164	1282	1512	
	45/40	94	628	691	815	
	85/75	341	2272	2502	2951	
15 1500	75/65	280	1868	2058	2427	
15 = 1500	65/55	221	1471	1619	1910	
	45/40	119	793	873	1030	
	85/75	412	2746	3024	3566	
17 = 1750	75/65	339	2258	2486	2932	
17 - 1730	65/55	266	1777	1957	2308	
	45/40	144	958	1055	1244	
	85/75	483	3219	3545	4181	
20 = 2000	75/65	397	2647	2915	3438	
20 - 2000	65/55	312	2083	2294	2706	
	45/40	168	1123	1237	1459	
	85/75 75/65	554 455	3693 3036	4066 3343	4796 3943	
22 = 2250	65/55	358	2390	2631	3943	
	45/40	193	1289	1419	1674	
	85/75	625	4166	4587	5410	
	75/65	514	3426	3772	4449	
25 = 2500	65/55	404	2696	2969	3501	
	45/40	218	1454	1601	1888	
27 = 2750	85/75	696	4639	5109	6025	
	75/65	572	3815	4201	4954	
	65/55	450	3002	3306	3899	
	45/40	243	1619	1783	2103	
	85/75	767	5113	5630	6640	
30 = 3000	75/65	631	4204	4629	5460	
	65/55	496	3309	3643	4297	
	45/40	268	1784	1965	2317	


The technical parameters are set according to the relevant standards. In fact, they may vary depending on the location of the convector, the cover grille, the connection type.

CONNECTION OPTIONS AND ACCESSORIES

- connection WITHOUT HEAD
- connection WITH ELECTROTHERMAL HEAD
- connection WITH CUSTOMER HEAD (after consultation)

The type of connection accessories varies according to the type and purpose of the convector. Connection accessories are packed separately and are not included in the standard convector delivery. Information on request from your sales representative or on our website.

REGULATION OPTIONS



IT IS POSSIBLE TO USE YOUR OWN REGULATION.

1) it is necessary to reset the control unit-EB-block (by default it is set to EB-B / EB-C)

2) external potential-free switching, e.g. via a boiler

EXAMPLE OF ORDER CODE



Orientation: L = left connection / P = right connection

*orientation and length complete according to the specification of the convector

ACOUSTIC PRESSURE

	Speed				
length L [mm]	speed 1	speed 2	speed 3		
	Equivalent acoustic pressure level LAeq,2m [dB]				
900	<20	22,1	35,1		
1000	<20	22,2	35,2		
1250	<20	22,5	35,5		
1500	<20	22,8	35,7		
1750	<20	23,0	36,0		
2000	<20	23,2	36,2		
2250	21,4	24,8	37,7		
2500	22,9	26,3	39,2		
2750	23,2	26,6	39,5		
3000	23,4	26,8	39,7		

measurement at a distance of 2m from the noise source at 1m height

INPUT POWER

length [mm]	power [W] EC MOTOR
900	5
1000	7
1250	8
1500	12
1750	13
2000	14
2250	19
2500	20
2750	24
3000	25

INDIVIDUAL CALCULATION

of technical data you can find on our website.

