



**Step 1:**  
Seal the bottom of the condo screwing the longer bolts C through smaller holes in G through smaller holes using allen key provided.

**Step 2:**  
Screw 3 double headed bolts B to bigger holes on the board using the short end, connect the three posts Q to the longer end of the bolts.

**Step 3:**  
Place wooden pieces E to the holes carved on G board and connect to H. Three small holes are carved on H for connection to G board.

**Step 4:**  
Connect L board to the three posts and H, caring about bolts usage. Three small holes are carved on L board for connection to H.

\* bolt D → hole 4  
bolt A → hole 1

**Step 5:**  
Connect the three posts T to L board. One B bolt is used to connect to the front post whilst bolts D are already placed for back side posts in step 4.

\* bolt D → hole 4  
bolt B → hole 2

**Step 6:**  
Place wooden pieces to the holes carved on L board and connect to K. Three small holes are carved on K for connection to L.

