

Specifications

Input	<input type="checkbox"/> 0...5 mA, <input type="checkbox"/> 0...20 mA, <input type="checkbox"/> 4...20 mA, <input type="checkbox"/> 0...10 mV, <input type="checkbox"/> 0...20 mV, <input type="checkbox"/> 0...50 mV, <input type="checkbox"/> 0...1 V, <input type="checkbox"/> 0...2 V, <input type="checkbox"/> 0...5 V, <input type="checkbox"/> 0...10 V, <input type="checkbox"/>
Power Supply (U_p)	<input type="checkbox"/> 12...24 VAC/DC, isolated, <input type="checkbox"/> 12...24 VAC/DC, non-isolated
Auxiliary Supply Output Consumption	<input type="checkbox"/> $\leq U_p$ (DC); $\leq 1.2 \cdot U_p$ (AC) less than 4 VA
Resolution	3.33% from span
Temperature Drift	0.02% from span for 1 °C
Operating Temperature / Humidity	-10...65 °C / 0...85% RH
Protection Class: front, terminals	<input type="checkbox"/> IP54, <input type="checkbox"/> IP65 / IP20

Warranty and Support

.....
serial number

.....
manufacturing date

QC check mark(passed)
(stamp)

BASI Instrument AB
p.o.box 53
SE-275 06 VOLLSJÖ, SWEDEN
tel: +46 (0)40 88009
fax: +46 (0)40 929877
e-mail: sales@basi.se

Warranty

BASI Instrument AB warrants this product to be free from defects in materials and workmanship for 2 years. If your unit is found to be defective within that time, we will promptly repair or replace it. This warranty does not cover accidental damage, wear or tear, or consequential or incidental loss. This warranty does not cover any defects caused by wrong transportation, storage, installation, or operating (see 'Specifications').

Technical support

In the unlikely event that you encounter a problem with your BASI device, please call your local dealer or contact directly our support team.

QD-8.2.4-WC

v4-12.09

BASI Instrument AB, P.O.Box 53, SE-275 06 VOLLSJÖ, SWEDEN
tel: +46 (0)40 88009, fax: +46 (0)40 929877, e-mail: info@basi.se



SLIM-SIZE BARGRAPH INDICATOR

BBI150

OPERATION MANUAL




Please read this Operation Manual before mounting and operating!
Save the Manual for future references!

Overview

BB150 is a slim-size process indicator for panel mounting, equipped with a 30-dot vertical LED bargraph with 0...100% range and accepting linear voltage or current signals at its input. In combination with a level transmitter, BB150 provides convenient level indication. Moving dot and moving bar modes of bargraph display are also available as well as custom bargraph design. Low priced, BB150 with its useful features and slim front design can be widely applicable for a vast range of industrial solutions.

Mounting and Wiring





Mounting

Place BB150 into a 21 x 93 mm panel cut-out and tighten into place using the enclosed mounting brackets.


Wiring

- ◆ To connect a 2-wire transmitter to your BB150, and supply both devices using an external non-isolated power source (see 'Specifications'), follow the left diagram.
- ◆ In case of isolated power supply source (see 'Specifications'), adhere to the second diagram.




- ◆ When connecting a 3-wire transmitter and a common non-isolated power supply source, follow the wiring diagram on the left.


Mounting and Wiring



- ◆ To connect a 3-wire transmitter and power it with isolated supply via the BB150's auxiliary supply output (to find if such is installed, see 'Specifications'), follow the left diagram.



- ◆ When connecting a 2-wire transmitter to your BB150, while using 2 separate galvanically isolated external supply sources, wire as illustrated on the left.



- ◆ To connect a 3-wire transmitter to your BB150, and supply each device via detached galvanically isolated external supply source, follow the diagram on the left.