

## Hipot (Withstanding Voltage) Tester AC Hipot Tester TOS5200

Highly-stable output with PWM Amp System 5 kV/100 mA (500 VA) AC Hipot test Short-circuit current 200 mA or more Rise time/Fall time control Equipped with RS232C and USB Interface



# An ideal AC Hipot Tester with ownership realized, built on 50 years of experience !

# Rise/Fall Time control function of the applied voltage

#### *Equipped with a Rise time/ Fall time control function*


Prevents from an excessive stress applied to the EUT or for standard tests.



# **Highly stable output**

#### Newly developed, high-efficiency PWM switching amplifier !

Providing a stable output of high voltage without being affected by AC line variation. Ensure the user to perform highly reliable testing with confidence, even in regions with large voltage variations. (Input voltage fluctuation rate:  $\pm 0.3$  %)



GIKIKUSUI TOS5200 AC WITHSTANDING

READY

50Hz

## Pursuing usability and safety

# All new smart design of control panel and output terminals!

Eliminates the projected components of output terminals, and equips with a new type of the LOW terminal. Pursuing the improvement of safety and a convenience in production line, such as providing the protection cover for the front panel.





▲ Output terminal Left: HIGH (red) Right: LOW (black, with lock function) View with the protection cover removed from front panel



# Reducing the tact time

Increasing the productivity!

Capable of setting the test time from 0.1 s

# *low cost of more than*

#### More than 50 years of experience to support "JAPAN-quality"

Our electronic safety tester has more than 50 years of history since the first product was released in 60's.

# High Precision High Resolution

#### ± 1.5 % of reading\*

High-precision measurement  $\pm 1.5$  % of reading \*(with voltmeter 500 V or higher, Ammeter 1 mA or higher)

# Supporting the World-wide input voltage

#### Universal usability !

Usable in any country without changing the input power supply.

#### Selectable output frequency ! Not rely on the input power environment.

It supplies the stable test voltage with

50/60 Hz frequencies.



▲ Rear panel

# AC Hipot Tester **TOS5200**

TOS5200 is designed for AC Hipot Test with 500 VA capacity and 200 mA short circuit current output capability. Equipped with the PWM amplifier, the TOS5200 can provide a stable & reliable output without being affected by AC power line. Therefore, it is a perfect solution for electronic equipment or devices complied to IEC, EN, UL, VDE and JIS etc. requirement. As TOS5200 covers most of features of our upper class model for AC Hipot Test, it achieves the superb cost / performance ratio for those who need 200 VA or 500 VA capacity, or both. Also, as it equips the Interlock function together with other safety features, operator can carry out the test with higher current value in safe.



#### The TOS5200 has many improvements from the predecessor !

#### • Comparison with the Kikusui previous model

Specificatio	on comparison item	TOS5200	TOS5050A		
	Output method	PWM switching amp system	Slide transformer method		
	Distortion	3 % or less	As per commercial power supply waveform		
Testuslites	Frequency	50 Hz or 60 Hz	Synchronized with commercial power supply waveform		
Test voltage	Output voltage waveform	Sine	Commercial power supply waveform		
	Voltage regulation	10 % or less	15 % or less		
	Input voltage variation	±0.3 %	-		
Test time	Minimum setting value	0.1 s	0.5 s		
restume	Accuracy	±(100 ppm + 20 ms) excluding Fall Time	±(100 ppm + 20 ms)		
	Upper limit setting	AC: 0.01 mA to 110 mA	AC: 0.1 mA to 110 mA		
	Lower limit setting	AC: 0.01 mA to 110 mA	AC: 0.1 mA to 110 mA		
Judgment feature	Accuracy	1.00 mA ≤ i: ±(1.5 % of set), i <1.00 mA: ±(1.5 % of set +30 μA)	Upper limit: ±(5 % + 20 µA)		
	Rise Time and Fall Time control features	3	-		
Voltmeter	Display	Digital	Digital, analog		
voitmeter	Measurement accuracy	±1.5 % of reading (V>500V)	±1.5 % f.s		
Voltmeter/Ammeter	Measurement method	True rms/mean-value	Mean-value/rms value		
RS232C Interface		POWER Switch and all function except Key lock	Output for data, test result		
	Weight	Approx. 14 kg (30.9 lbs)	Approx. 15 kg (33.07 lbs)		
Other Input power supply		100 Vac to 240 Vac	100 V ± 10 %		
Aş	opearance				



#### Highly stable output is realized with PWM Switching Amplifier!


Tek Stop

Che SOOV

Equipped with the PWM switching amplifier system, the TOS5200 realizes highly stable output without influenced by input form AC line.

A conventional Hipot Tester boosts and outputs the AC line's input voltage through the use of a slide transformer system With this slide transformer system, input voltage fluctuations will affect the output, preventing test from being performed properly. Since the TOS5200 equips with a high-efficient PWM amplifier that can output a stable high-voltage without being affected by the variation of AC power line, users can perform "safe", "stable", and highly "reliable" tests with confidence, even in regions with large voltage variations.

#### The output waveform is essential factor in Hipot (Withstanding oltage) testing!



#### High-Accuracy = Less measurement error! "+/-1.5 % of reading" versus "+/-1.5 % f.s."

49.80 %

TOS5200 > reading: Accuracy is specified against reading value.

TOS5050A ► f.s: Accuracy is specified against full scale.

When using TOS5200 at 1500 V output measurement, the max error would be 1500 V(reading value) x 1.5 % = 22.5 V On the other hand, when using equipment which specifies its accuracy with "+/- 1.5 % f.s.", the max error could be 2500 V(max voltage) x 1.5 % =37.5 V (it needs to set the range 0 to 2.5 kV) So, there is 15 V difference of max measurement error at 1500 V output.




#### Capable of Test Time setting from 0.1 s, which enables to reduce the tact time !

TOS5200 can set the test time from 0.1 sec without sacrificing measurement accuracy.

#### This makes test time 5 times faster compared to the TOS5050A (max test time:0.5sec) and it leads to reduce the tact time.


Reduction of the tact time leads to improve the productivity, so it has been an issue that reducing the tact time may cause to worsen the measurement accuracy when the test time is faster than measurement respond speed.







#### Rise time / Fall time control function

The rise time control function is to prevent the excessive stress that is being applied to the EUT (test object). The Hipot (Withstanding voltage) test is conducted to verify the safety performance of the EUT and which test voltage for Hipot (Withstanding voltage) test is applied approximately five to ten times greater than the voltage that handles by the EUT. If a high voltage is applied rapidly with no rise time, the transitional large voltage (current) will be occurred, and it may cause a damage to the EUT. For this reason, safety standards stipulate the procedure of Hipot (Withstanding voltage) test, and the test voltage must be gradually increased to the specified voltage when the test is performed. The rise time control function adopted in the in the TOS5300 Series can set the voltage rise time from 0.1s to 10.0 s (at a resolution of 0.1 s) and also it is capable to set the 50 % (fixed) of the applied test voltage. In addition, the fall time control function enables to decrease the test voltage gradually after the completion of a PASS judgement. The voltage fall time is fixed at 0.1 s (OFF is also selectable).






#### Rise Time control function



The Rise time control function enables you to increases the test voltage gradually to reach the setting voltage while the AC Hipot (Withstanding voltage) test is conducted. The voltage rise time can be set from 0.1 s to 10.0 s at a resolution of 0.1s.

▲Rise time control waveform (example)

#### Fall Time control function



▲Fall time control waveform (example)

The Fall time control fun-ction enables you to decrease the test voltage gradually when the PASS judgment is made at the AC Hipot (Withstanding voltage) test. The voltage fall time is fixed at 0.1 s. (OFF is also selectable).

# Improved the setting resolution of the leak current by 0.01 mA !

#### TOS5200 is **can set the current limit from0.01 mA to 110 mA**. (TOS5050A: 0.1 mA to 110 mA)

- Enable to clarify the actual value of device under test (DUT)
- The setting resolution of the lower limit setting has been improved from the previous model ,it enables to defect the failure more accurately.



▲AC Hipot (Withstanding voltage) test settings display (example)

Unless specified otherwise, the specifications are for the following settings and conditions. • The warm-up time is 30 minutes. • TYP: These are typical values. These values do not guarantee the performance of the product. • rdng: Indicates the readout value. • set: Indicates a setting. • f.s: Indicates full scale.

#### Withstanding voltage tester

	0.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1.1									
	Output range		0.05 kV to 5.00 kV							
		Setting accuracy	-	t + 20 V) [at no l	bad]					
		Setting range	0.00 kV to 5.50 kV							
		Resolution	10 V STEP							
	Max. rated ou	tput *1	500 VA (5 kV/100 mA)							
	Max. rated vo	Itage	5 KV							
	Max. rated current		100 mA [output voltage 0.5 kV or higher]							
AC	Transformer r	ating	500 VA							
Output	Output voltage waveform *2		Sine							
section	Distortion		If the output voltage is 0.5 kV or more: 3 % or less (when no load or a pure resistive load is connected)							
	Crest factor		Within $\sqrt{2} \pm 3$ % (output voltage 800 V or higher, at no load)							
	Frequency		50 Hz or 60 Hz							
		Accuracy	± 0.5 % (exc	luding during vo	Itage rise time)					
	Voltage regula	ation	10 % or less	(when changing	g from maximum rated loa	d to no load)				
	Input voltage	variation	±0.3 % (5 k\	/ when no load	is connected; power supp	ly voltage: 90 V to	250 V)			
	Short-circuit of	current	200 mA or n	nore (when the d	output voltage is 1.0 kV or	greater)				
	Output metho	d	PWM switch	ning						
Start voltage	1		The voltage	at the start of w	ithstanding voltage tests c	an be set to 50 %	of the te	st voltage.		
Limit voltage					can be set . AC: 0.00 kV					
			-		e specified value + 350 V		e specifie	ed value - 3	50 V.	
Output voltage mor	nitor feature				ective features are activat		.,			
		Measurement range	0.000 kV to	6.500 kV AC						
		Display	0.000 kV							
Voltmeter	Digital	Accuracy	V < 500 V: ±	(1.5 % of reading	ng + 20 V), V ≥ 500 V: ±1.	5 % of reading				
	_	Response *3	True rms, Average value response/rms display switchable							
		Hold feature	After a test i	s finished, the n	easured voltage is retaine	ed until the PASS	or FAIL ju	udgment is	cleared.	
		Measurement range	0.00 mA to 7							
			i = measure							
		Display								
			i	< 1 mA	1 mA ≤ i < 10 mA	10 mA ≤ i < 10	0 mA	100	mA≤i	
Ammeter	Digital		□.	0.000 mA 0.000 mA 00.00 mA			A 000.0 mA			
		Accuracy *4	1.00  mA < i + 1/1.5%  of roading i < $1.00  mA + 1/1.5%  of roading + 20.4 A$							
		Accuracy 4	1.00 mA ≤ i: ± (1.5 % of reading), i < 1.00 mA: ± (1.5 % of reading + 30 μA) True rms/ Mean-value response rms display Can be switched							
		Doopopoo *2	True rme/M	oon value roon	nao rmo diaploy Cap bo o	witchod				
		Response *3						amont in old	arad	
		Response *3 Hold feature			nse rms display Can be s neasured current value is r		PASS jud	gment is cle	eared.	
					easured current value is r		PASS jud		eared.	SIGNAL I/O
			After a test i Judgment	s finished, the n	hod	etained until the F	Display FAIL LE	ED lights;		
			After a test i Judgment UPPER	Judgment met	easured current value is r	etained until the F	Display FAIL LE UPPER	ED lights;		Generates
			After a test i Judgment	Judgment met	hod t is greater than or equal t e output is turned off, and	etained until the F	Display FAIL LE UPPER display	ED lights; R is ed	Buzzer	Generates
			After a test i Judgment UPPER	If a current that is detected, the judgment occu	hod t is greater than or equal t e output is turned off, and	etained until the F to the upper limit an UPPER FAIL	Display FAIL LE UPPER	ED lights; R is ed	Buzzer	Generates
			After a test i Judgment UPPER FAIL	s finished, the n Judgment med If a current tha is detected, th judgment occu If a current tha detected, the	heasured current value is r hod it is greater than or equal i e output is turned off, and urs. it is less than or equal to tl putput is turned off, and a	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL	Display FAIL LE UPPER display on the s	ED lights; t is ed screen ED lights;	Buzzer	Generates a U-FAIL signal
			After a test i Judgment UPPER FAIL LOWER	s finished, the n Judgment met If a current tha is detected, th judgment occu If a current tha detected, the judgment occu	heasured current value is r hod it is greater than or equal l e output is turned off, and urs. It is less than or equal to th output is turned off, and a urs. This judgment is not p	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during	Display FAIL LE UPPER displaye on the s FAIL LE LOWEF	ED lights; t is ed screen ED lights; t is	Buzzer	Generates a U-FAIL signal Generates
	Judament me	Hold feature	After a test i Judgment UPPER FAIL	s finished, the n Judgment met If a current tha is detected, th judgment occu If a current tha detected, the judgment occu voltage rise tin	hod ti is greater than or equal to e output is turned off, and urs. ti is less than or equal to ti boutput is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the	Display FAIL LE UPPER displaye on the s FAIL LE LOWEF displaye	ED lights; R is ed screen ED lights; R is ed on the	Buzzer       ON	Generates a U-FAIL signal Generates
	Judgment me judgment ope	Hold feature	After a test i Judgment UPPER FAIL LOWER	s finished, the n Judgment met If a current tha is detected, th judgment occu If a current tha detected, the judgment occu voltage rise tin	heasured current value is r hod it is greater than or equal l e output is turned off, and urs. It is less than or equal to th output is turned off, and a urs. This judgment is not p	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the	Display FAIL LE UPPER displaye on the s FAIL LE LOWEF	ED lights; R is ed screen ED lights; R is ed on the	Buzzer       ON	Generates a U-FAIL signal Generates
	U U	Hold feature	After a test i Judgment UPPER FAIL LOWER FAIL	s finished, the n Judgment met If a current tha is detected, th judgment occt off a current tha detected, the judgment occt voltage rise tin voltage fall tim tests.	heasured current value is r hod ti is greater than or equal to e output is turned off, and irrs. ti is less than or equal to ti boutput is turned off, and a irrs. This judgment is not p ne (Rise Time) of all tests te (Fall Time) of AC withsta	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen	ED lights; R is ed screen ED lights; R is ed on the LED lights;	Buzzer       ON       ON	Generates a U-FAIL signal Generates a U-FAIL signal
Judament feature	U U	Hold feature	After a test i Judgment UPPER FAIL LOWER	s finished, the n Judgment met If a current tha is detected, th judgment occu Voltage rise ti voltage fall tim tests.	heasured current value is r hod ti is greater than or equal to e output is turned off, and urs. ti is less than or equal to tt poutput is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests	etained until the F to the upper limit an UPPER FAIL ne lower limit is LOWER FAIL erformed during and during the and ing voltage problems, the	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS I display	ED lights; R is ed screen ED lights; R is ed on the	Buzzer       ON	Generates a U-FAIL signal Generates a U-FAIL signal Generates
Judgment feature	U U	Hold feature	After a test i Judgment UPPER FAIL LOWER FAIL PASS	s finished, the n Judgment met If a current tha is detected, the judgment occu Voltage rise tin voltage fall tim tests. If the specified output is turned	heasured current value is r hod ti s greater than or equal to e output is turned off, and urs. ti s less than or equal to tt butput is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests te (Fall Time) of AC withsta time elapses without any d off, and a PASS judgment	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs.	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS I display screen	ED lights; R is ed screen ED lights; R is ed on the LED lights; ed on the	Buzzer ON ON ON	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal
Judgment feature	U U	Hold feature	After a test i Judgment UPPER FAIL LOWER FAIL PASS	s finished, the n Judgment met If a current tha is detected, th judgment occu If a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specified output is turne DLD is enabled,	hod hod it is greater than or equal to e output is turned off, and urs. It is less than or equal to th boutput is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta time elapses without any d off, and a PASS judgme the PASS signal is generat	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs.	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the	ED lights; ED lights; Ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
Judgment feature	U U	Hold feature	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS H0 • The UPPE	s finished, the n Judgment met If a current tha is detected, th judgment occu If a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specified output is turne DLD is enabled,	heasured current value is r hod ti s greater than or equal to e output is turned off, and urs. ti s less than or equal to tt butput is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests te (Fall Time) of AC withsta time elapses without any d off, and a PASS judgment	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs.	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the	ED lights; ED lights; Ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP sign
Judgment feature	U U	Hold feature	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The UPPE signal.	s finished, the n Judgment met If a current tha is detected, th judgment occi voltage rise ti voltage rise ti voltage fall tim tests. If the specified output is turned DLD is enabled, R FAIL and LC	hod hod it is greater than or equal to e output is turned off, and urs. It is less than or equal to th boutput is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta time elapses without any d off, and a PASS judgme the PASS signal is generat	etained until the F to the upper limit an UPPER FAIL erformed during and during the anding voltage problems, the nt occurs.	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the	ED lights; ED lights; Ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP sign
Judgment feature	U U	Hold feature	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The PPE signal. • The FAIL a • For PASS	s finished, the n Judgment met If a current tha is detected, th judgment occu off a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I	hod ti is greater than or equal to e output is turned off, and urs. ti is less than or equal to to output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta ti me elapses without any d off, and a PASS judgme the PASS signal is genera WER FAIL signals are go r volume levels can be chi- ength of time that the buzz	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ated continuously enerated continuously enerated continuously enerated continuously enerated continuously	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS i display screen until the busly until	ED lights; R is ed screen ED lights; R is ed on the LED lights; d on the TOS5300 S iil the TOS5	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
Judgment feature	judgment ope	Hold feature	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The PASS signal. • The FAIL a • For PASS Even if PAS	s finished, the n Judgment met If a current tha is detected, th judgment occu off a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena	hod ti s greater than or equal to e output is turned off, and urs. ti s less than or equal to th output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta time elapses without any d off, and a PASS judgme the PASS signal is genera WER FAIL signals are generations and the solution of the solution of the solution of the solution were the the solution of the solution of the solution of the solution of the solution of the solution of the solution the the solution of the solution of the solution of the solution the the solution of the	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ated continuously enerated continuously enerated continuously enerated continuously enerated continuously	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS i display screen until the busly until	ED lights; R is ed screen ED lights; R is ed on the LED lights; d on the TOS5300 S iil the TOS5	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
Judgment feature	U U	Hold feature	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The PPE signal. • The FAIL a • For PASS	s finished, the n Judgment met If a current tha is detected, th judgment occu off a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena	hod ti is greater than or equal to e output is turned off, and urs. ti is less than or equal to to output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta ti me elapses without any d off, and a PASS judgme the PASS signal is genera WER FAIL signals are go r volume levels can be chi- ength of time that the buzz	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ated continuously enerated continuously enerated continuously enerated continuously enerated continuously	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS i display screen until the busly until	ED lights; R is ed screen ED lights; R is ed on the LED lights; d on the TOS5300 S iil the TOS5	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
ludgment feature	judgment ope	Hold feature thod and ration	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The UPPE signal. • The FAIL a • For PASS Even if PAS 0.01 mA to 1	s finished, the n Judgment met If a current tha is detected, th judgment occu off a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena	hod ti is greater than or equal te e output is turned off, and urs. ti is less than or equal to tt output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta ti me elapses without any d off, and a PASS judgme the PASS signal is genera WER FAIL signals are generative wer solume levels can be chi-	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ated continuously enerated continuously enerated continuously enerated continuously enerated continuously	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS i display screen until the busly until	ED lights; R is ed screen ED lights; R is ed on the LED lights; d on the TOS5300 S iil the TOS5	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP sign
ludgment feature	judgment ope	Hold feature thod and ration	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The UPPE signal. • The FAIL a • For PASS Even if PAS 0.01 mA to 1 0.01 mA to 1	s finished, the n Judgment met If a current tha is detected, th judgment occu voltage rise tin voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena 110 mA	hod ti is greater than or equal te e output is turned off, and urs. ti is less than or equal to tt output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta ti me elapses without any d off, and a PASS judgme the PASS signal is genera WER FAIL signals are generative wer solume levels can be chi-	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ted continuously enerated continuously	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS i display screen until the busly until	ED lights; R is ed screen ED lights; R is ed on the LED lights; d on the TOS5300 S iil the TOS5	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
ludgment feature	judgment ope Upper limit se Lower limit se	Hold feature thod and ration tting tting turacy *4	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The FAIL a • For PASS Even if PAS 0.01 mA to 1 0.01 mA to 1 1.00 mA ≤ i:	s finished, the n Judgment met If a current tha is detected, the judgment occu voltage rise tin voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena 110 mA 110 mA / OFF ± (1.5 % of set),	hod ti is greater than or equal te e output is turned off, and urs. ti is less than or equal to tt output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta ti me elapses without any d off, and a PASS judgment the PASS signal is genera WER FAIL signals are generative WER FAIL signals are generative ength of time that the buzzer bled, the buzzer turns off	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ted continuously enerated continuously enerat	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the busly unt	ED lights; ED lights; ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S iil the TOS5 2 seconds.	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signa Generates a U-FAIL signa Generates a PASS signal ves a STOP sign
Judgment feature	judgment ope Upper limit se Lower limit se Judgment acc	Hold feature thod and ration tting tting turacy *4	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The UPPE signal. • The FAIL a • For PASS Even if PAS 0.01 mA to 1 0.01 mA to 1 1.00 mA ≤ i: Calculates t	s finished, the n Judgment met If a current tha is detected, th judgment occu off a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena 110 mA 110 mA / OFF ± (1.5 % of set), he current's true	hod ti s greater than or equal to e output is turned off, and urs. ti s less than or equal to th output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withsta time elapses without any d off, and a PASS judgment the PASS signal is generative WER FAIL signals are grown the pass signal is generative WER FAIL signals are grown the buzzer turns off i < 1.00 mA: ± (1.5 % of signals)	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ted continuously enerated continuously enerat	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the busly unt	ED lights; ED lights; ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S iil the TOS5 2 seconds.	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP sign
Judgment feature	judgment oper Upper limit se Lower limit se Judgment acc Current detec	Hold feature thod and ration tting tting turacy *4 tion method	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The UPPE signal. • The FAIL a • For PASS Even if PAS 0.01 mA to 1 0.01 mA to 1 1.00 mA ≤ i: Calculates t	s finished, the n Judgment met If a current tha is detected, th judgment occu off a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena 110 mA 110 mA / OFF ± (1.5 % of set), he current's true vith the rms of a	hod ti s greater than or equal te e output is turned off, and urs. ti s less than or equal to tt output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withste construction of AC withste the PASS signal is generate WER FAIL signals are generate WER FAIL signals are generated the pass signal is generated the signal i	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ted continuously enerated continuously enerat	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the busly unt	ED lights; ED lights; ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S iil the TOS5 2 seconds.	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
Judgment feature	judgment oper Upper limit se Lower limit se Judgment acc Current detec Calibration	Hold feature thod and ration tting tting turacy *4 tion method	After a test i Judgment UPPER FAIL LOWER FAIL PASS • If PASS HO • The UPPE signal. • The FAIL a • For PASS Even if PAS 0.01 mA to 1 0.01 mA to 1 1.00 mA ≤ i: Calculates t Calculates t	s finished, the n Judgment met If a current tha is detected, th judgment occu off a current tha detected, the judgment occu voltage rise tin voltage fall tim tests. If the specifier output is turne DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena 110 mA 110 mA / OFF ± (1.5 % of set), he current's true vith the rms of a	hod ti s greater than or equal te e output is turned off, and urs. ti s less than or equal to tt output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withste construction of AC withste the PASS signal is generate WER FAIL signals are generate WER FAIL signals are generated the pass signal is generated the signal i	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. ted continuously enerated continuously enerat	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the busly unt	ED lights; ED lights; ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S iil the TOS5 2 seconds.	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
	judgment oper Upper limit se Lower limit se Judgment acc Current detec Calibration	Hold feature thod and ration tting tting turacy *4 tion method me Resolution	After a test i Judgment UPPER FAIL LOWER FAIL PASS If PASS HO The UPPE signal. The FAIL a FOP PASS O.01 mA to 1 0.01 mA to 1 1.00 mA ≤ i: Calculates t Calculates t Calculates t	s finished, the n Judgment met If a current tha is detected, th judgment occi Voltagerise ti voltage rise ti voltage fall tim tests. If the specified output is turned DLD is enabled, ER FAIL and LC and PASS buzze judgments, the I SS HOLD is ena 110 mA / OFF ± (1.5 % of set), he current's true vith the rms of a s	hod ti s greater than or equal te e output is turned off, and urs. ti s less than or equal to tt output is turned off, and a urs. This judgment is not p ne (Rise Time) of all tests le (Fall Time) of AC withste construction of AC withste the PASS signal is generate WER FAIL signals are generate WER FAIL signals are generated the pass signal is generated the signal i	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. tet d continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously this value with the sistive load	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the busly unt	ED lights; ED lights; ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S iil the TOS5 2 seconds.	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
	judgment ope Upper limit se Lower limit se Judgment acc Current detec Calibration Voltage rise ti	Hold feature thod and ration tting tting turacy *4 tion method me Resolution	After a test i Judgment UPPER FAIL LOWER FAIL PASS If PASS HO The UPPE signal. The FAIL a FOR PASS Even if PAS 0.01 mA to 1 0.01 mA to 1 1.00 mA 4 i: Calculates t Calculates t Calculates t 0.1 s to 10.0	s finished, the n Judgment met If a current tha is detected, th judgment occi voltage rise ti voltage rise ti voltage fall tim tests. If the specified output is turned DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena 110 mA / OFF ± (1.5 % of set), he current's true vith the rms of a rs	hod ti s greater than or equal to e output is turned off, and irs. ti s less than or equal to th output is turned off, and a urs. This judgment is not p e (Rise Time) of all tests te (Fall Time) of AC withsta the PASS signal is genera WER FAIL signals are gr r volume levels can be ch- ength of time that the buzz bled, the buzzer turns off i < 1.00 mA: ± (1.5 % of se rms value and compares sine wave using a pure re- ten a PASS judgment occe	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. tet d continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously this value with the sistive load	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the busly unt	ED lights; ED lights; ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S iil the TOS5 2 seconds.	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa
Judgment feature	judgment oper Upper limit se Lower limit se Judgment acc Current detec Calibration Voltage rise ti Voltage fall tir	Hold feature thod and ration tting tting turacy *4 tion method me Resolution	After a test i Judgment UPPER FAIL LOWER FAIL PASS If PASS HO The UPPE signal. The FAIL a FOR PASS Even if PAS 0.01 mA to 1 0.01 mA to 1 1.00 mA 4 i: Calculates t Calculates t Calculates t 0.1 s to 10.0 0.1 s 0 OFF ( 0.1 s to 999	s finished, the n Judgment met If a current tha is detected, th judgment occi voltage rise ti voltage rise ti voltage fall tim tests. If the specified output is turned DLD is enabled, R FAIL and LC and PASS buzze judgments, the I SS HOLD is ena 110 mA / OFF ± (1.5 % of set), he current's true vith the rms of a s fonly enabled with	hod ti s greater than or equal to e output is turned off, and irs. ti s less than or equal to th output is turned off, and a urs. This judgment is not p e (Rise Time) of all tests te (Fall Time) of AC withsta the elapses without any d off, and a PASS judgment the PASS signal is genera WER FAIL signals are gr r volume levels can be ch- ength of time that the buzz bled, the buzzer turns off i < 1.00 mA: ± (1.5 % of se rms value and compares sine wave using a pure re hen a PASS judgment occo off (TIMER OFF)	etained until the F to the upper limit an UPPER FAIL he lower limit is LOWER FAIL erformed during and during the anding voltage problems, the nt occurs. tet d continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously enerated continuously this value with the sistive load	Display FAIL LE UPPER display on the s FAIL LE LOWEF display screen PASS display screen until the busly unt	ED lights; ED lights; ed screen ED lights; R is ed on the LED lights; ed on the TOS5300 S iil the TOS5 2 seconds.	Buzzer       ON       ON       ON       eries recei	Generates a U-FAIL signal Generates a U-FAIL signal Generates a PASS signal ves a STOP signa

#### \*1. Regarding the output time limits:

Taking size, weight, and cost into consideration, the heat dissipation capability of the voltage generator that is used for withstanding voltage tests has been designed to be one half that of the rated output. Use the TOS5300 Series within the following limits. If you use the product in a manner that exceeds these limits, the output section may overheat, and the internal protection circuits may be

activated. If this happens, stop testing, and wait until the TOS5300 Series returns to its normal temperature.

Ambient temperature		Pause time	Output time
t ≤ 40 °C	50 mA < i ≤ 110 mA	Greater than or equal to the output time	30 min. max.
	i ≤ 50 mA	Not necessary	Continuous output possible
		(Output time = voltag	e rise time + test time + voltage fall time)

#### \*2. Regarding the test voltage waveform:

Waveform distortions may occur if an DUT whose capacitance is dependent on voltage (for example, an DUT that consists of ceramic capacitors) is connected as the load. However, if the test voltage is 1.5 kV, the effect of a capacitance of 1000 pF or less can be ignored. Because the product's high-voltage power supply uses the PWM switching method, if the test voltage is 500 V or less, the switching and spike noise proportions are large. The lower the test voltage, the greater the waveform is distorted.

\*3. For both True rms and Mean-value response, 50 ms or above response time is required to satisfy the measurement accuracy.

\*4. Regarding ammeter and judgment accuracy:

During AC withstanding voltage tests, current also flows in the stray capacitance of items such as the measurement leads and jigs. This current that flows in the stray capacitances is added to the current that flows in the DUT, and the sum of these currents is measured. Especially if you want to perform judgments with high sensitivity and accuracy, it is necessary to consider methods to limit the current that flows in these stray capacitances, such as by adding upper and lower limits.

Output voltage	1 kV	2 kV	5 kV
When using 350 mm long test leads that are suspended in air (TYP)	2 µA	4 μΑ	10 µA
When using the accessory, high test lead TL31-TOS (TYP)	16 µA	32 µA	80 µA

In case of 70 % humidity or higher, it is considerable to add 50 µA on the Limit value.

#### Other features / Interfaces

Test mo	ode					
	Double action	on feature	Tests can only be started by pressing and releasing STOP and then pressing START within 0.5 seconds of releasing the STOP switch.			
	Length of tim	ne to maintain a PASS judgment result	You can set the length of time to maintain a PASS judgment: 50 ms, 100 ms, 200 ms, 1 s, 2 s,5 s, or HOLD.			
	Momentary	feature	Tests are only executed while the START switch is held down.			
	Timer feature		This feature enables you to prevent remotely transmitted stop signals from clearing FAIL judgments and PROTECTION modes.			
			This feature finishes tests when the specified time elapses.			
			If output voltage exceeds "setting + 350 V" or is lower than "setting - 350 V," the TOS5200 switches to PROTECTION mode, output is turned off, and testing finishes.			
	Memory		Up to three sets of test conditions can be saved to memory.			
	Key lock		Locks panel key operations (settings and changes).			
Protect	ive features		Under any of the following conditions, the TOS5200 switches to the PROTECTION state, immediately turns output off, and stops testing. A message is displayed on the screen.			
	Interlock Pro	otection	An interlock signal has been detected. An error was detected in the power supply.			
	Power Supp	ly Protection				
	Volt Error Pr	rotection	While monitoring the output voltage, a voltage outside of the rated limits was detected. AC or DC withstanding voltage tests: ±350 V			
	Over Load F	Protection	During a withstanding voltage test, a value that is greater than or equal to the output limit power was specified. AC withstanding voltage test: 550 VA.			
	Over Heat F	Protection	The internal temperature of the TOS5200 became too high.			
	Over Rating Protection		During a withstanding voltage test, the output current was generated for a length of time that exceeds the regulated time			
	Remote Protection		A connection to or disconnection from the front-panel REMOTE connector was detected.			
	SIGNAL I/O Protection		The rear-panel SIGNAL I/O connector's ENABLE signal has changed.			
	USB Protection		The USB connector has been disconnected while the TOS5200 was being controlled through the USB interface.			
		USB	USB Specification 2.0			
late of a		RS232C *1	D-SUB 9-pin connector on the rear panel (compliant with EIA-232-D) All functions other than the POWER switch and KEY-LOCK			
Interfac		REMOTE	Front-panel 9-pin MINI DIN connector. By connecting an optional device to this connector, you can control the starting and stopping of tests remotely.			
		SIGNAL I/O	Rear-panel D-sub 25-pin connector			

\*1. "Talk mode" can be set, when RS232C is used as comunication interface.

Talk mode	Description				
0	It responds only for commands from PC. (Default setting)				
	It responds automatically for start and end test, and returns the status, setting value, measured value.				
1	Response at start		<start></start>		
	Response at end of test	Status	<pass>, <u_fail>, <l_fail>, <prot>, <about></about></prot></l_fail></u_fail></pass>		
		Setting value, Measured value	Test No., Programme No., Test mode, Measured voltage, Measured current, Test time		

#### Specifications

#### General

00110						
Display			LCD: LED back custom indicators			
	Installation location		Indoors, at a height of up to 2000 m			
Environ- ment	Spec guaranteed range temperature/humidity		5 °C to 35 °C (41 °F to 95 °F)/20 %rh to 80 %rh (no condensation)			
	Operating range temperature/humidity		0 °C to 40 °C (32 °F to 104 °F)/20 %rh to 80 %rh (no condensation)			
	Storage range temperature/humidity		-20 °C to 70 °C (-4 °F to 158 °F)/90 %rh or less (no condensation)			
	Nominal volta	ge range (allowable voltage range)	100 VAC to 240 VAC (90 VAC to 250 VAC)			
Power	Power	When no load is connected (READY)	100 VA or less			
supply	consumptio	When rated load isconnected	800 VA max.			
	Allowable free	quency range	47 Hz to 63 Hz			
Insulation	resistance (be	tween AC LINE and the chassis)	30 MΩ or more (500 VDC)			
Withstand	ding voltage (be	tween AC LINE and the chassis)	1500 Vac, 1 minute			
Earth con	itinuity		25 Aac, 0.1 Ω or less			
Electromagnetic compatibility (EMC) *1 *2			MC) *1 *2 MC) *1 *2 Complies with the requirements of the following directive and stan-dards. EMC Directive 2014/30/EU EN 61326-1(ClassA *3), EN 55011(ClassA *3, Group1 *4), EN 61000-3-2, EN 61000-3-3 Applicable under the following conditions. The maximum length of all cabling and wiring connected to the TOS is less than 2.5 m. Shielded cables are being used when using the SIGNAL I/O. The high-voltage test lead TL31-TOS is being used. Electrical discharges are not occurring outside the DUT.			
Safety *1			Complies with the requirements of the following directive and standard. Low Voltage Directive 2014/35/EU *2, EN 61010-1 (Class I *5 Pollution degree 2 *6)			
Dimensions (mm(inches))(maximum)			320 (12.6") (330(12.99")) W × 132(5.2") (150(5.91")) H × 350(13.78") (420(16.54")) D			
Weight			Approx. 14 kg (30.9 lbs)			
Accessories			Power cord : 1pc. / High test lead (TL31-TOS) : 1set (1 red wire and 1 black wire, each with alligator clips); 1.5 m / SIGNAL I/O plug : 1 set (assembly type) / High-voltage warning sticker : 1pc. / Setup Guide / Quick Reference(1 each for English and Japanese) / Safety informaion / CD-R			

\*1 Does not apply to specially ordered or modified TOS5200s.


\*2 Limited to products that have the CE mark on their panels. Not be in compliance with EMC limits unless the ferrite core is attachedon the cable for connection of J1 connector. \*3 This is a Class A equipment. The TOS5200 is intended for use in an industrial environment. This product may cause interferenceif used in residential areas. Such use must be avoided

unless the user takes special measures to reduce electromagnetic emis-sions to prevent interference to the reception of radio and television broadcasts. \*4 This is a Group 1 equipment. The TOS5200 does not generate and/or use intentionally radio-frequency energy, in the from of elec-tromagnetic radiation, inductive and/or capacitive

coupling, for the treatment of material or inspection/analysis purpose.

\*5 This is a Class I equipment. Be sure to ground the TOS5200's protective conductor terminal. The safety of this product is onlyguaranteed when the product is properly grounded. \*6 Pollution is addition of foreign matter (solid, liquid or gaseous) that may produce a reduction of dielectric strength or surface resis-tivity. Pollution Degree 2 assumes that only nonconductive pollution will occur except for an occasional temporary conductivitycaused by condensation.

#### Outline drawing



#### **TU01-TOS Option(s) for Electrical Safety Testers**

The TU01-TOS is a terminal unit that converts the 25 pin SIGNAL I/O connector of the Kikusui TOS5200 Withstanding Voltage Tester to the 14 pin SIGNAL I/O connector of the TOS5050A/ 5051A. You can insert this unit between a controller and a TOS5200 to perform the same external control that you can perform on the TOS5050A/ 5051A.



# KIKUSUI

#### **KIKUSUI ELECTRONICS CORPORATION**

1-1-3, Higashiyamata, Tsuzuki-ku, Yokohama, Kanagawa, 224-0023, Japan Phone:(+81)45-593-0200, Facsimile:(+81)45-593-7591, https://global.kikusui.co.jp/

KIKUSUI AMERICA, INC. 1-310-214-0000 www.kikusuiamerica.com 3625 Del Amo Blvd, Suite 160, Torrance, CA 90503 

Phone : 310-214-0000 Facsimile : 310-214-0014

KIKUSUI TRADING (SHANGHAI) Co., Ltd. www.kikusui.cn Room 305, Shenggao Building, NO. 157, Aldi Ala 1000, Strangers Phone : 021-5887-9067 Facsimile : 021-5887-9069 Room 305, Shenggao Building, No. 137, Xianxia Road, Shanghai City, China

For our local sales distributors and representatives, please refer to "sales network" of our website

Printed in Japan

#### Distributor/Representative

All products contained in this catalogue are equipment and devices that are premised on use under the supervision of qualified personnel, and are not designed or produced for home-use or use by general consumers. ■ Specifications, design and so forth are subject to change without prior notice to improve the quality. ■ Product names and prices are subject to change and production may be discontinued when necessary. ■ Product names, company names and brand names contained in this catalogue represent the respective registered trade name or trade mark. Colors, textures and so forth of photographs shown in this catalogue may differ from actual products due to a limit el object deliver and so form of photographics anown in this catalogue may mile from action photographics due to a limit efficient of photographics anown in this catalogue in provide the information as accurate as possible for this catalogue, certain details have unavoidably been omitted due to limitations in space. If you find any misprints or errors in this catalogue, it would be appreciated if you would inform us. I Please contact our distributors to confirm specifications, price, accessories or anything that may be unclear when placing an order or concluding a purchasing agreement.